11) Publication number:

**0 113 516** A2

(12)

#### **EUROPEAN PATENT APPLICATION**

(21) Application number: 83307078.2

(5) Int. Ct.3: G 06 F 9/46

22 Date of filing: 18.11.83

30 Priority: 26.11.82 GB 8233733

43 Date of publication of application: 18.07.84 Bulletin 84/29

B4 Designated Contracting States: DE FR GB IT NL SE (1) Applicant: INMOS LIMITED Whitefriars Lewins Mead Bristol BS1 2NP(GB)

72 Inventor: May, Michael David 124 Pembroke Road Clifton Bristol BS8 3ER(GB)


(2) Representative: Palmer, Roger et al, PAGE, WHITE & FARRER 5 Plough Place New Fetter Lane London EC4A 1HY(GB)

(54) Microcomputer.

....--

② A microcomputer comprising memory (1820.211 and processor (12) is arranged to securite a plurality of concurrent processes and share its time between them. The microcomputer includes means (53) for indicating a current process as well as a collection of processes awaining execution. Processes may be added to the collection of processes awaining means is provided to indicate the next process indicating means is provided to indicate the next process indicating means is provided to indicate the next process indicating means is provided to indicate the next process indicating means is provided to indicate the next process indicating means (10.20) is proper processes [12,33,34] on the same microcomputer. The ventronisation means (10.50) in any schedule a process by adding it to the collection or terminating execution of the current process.

P 0 113 516 A



## MICROCOMPUTER

The invention relates to computers including microcomputers.

## BACKGROUND TO THE INVENTION

Microcomputers generally comprise a processor and memory and may operate in accordance with a sequence of instructions derived from a stored program. The instructions may include a so-called "function" selected from a set of selectable functions and which the define the operation which is carried out by the processor in response that instruction. Processors may wish to communicate messages between different processes. Difficulties have previously arisen in effecting rapid and satisfactory communication between processes on the same microcomputer and between different microcomputers. Furthermore difficulties have arisen in scheduling and descheduling processes to permit a processor to share its time between a plurality of concurrent processes.

### OBJECTS OF THE INVENTION

It is an object of the present invention to provide an improved microcomputer in which a processor may share its time between a plurality of concurrent processes.

It is a further object of the present invention to provide an improved microcomputer in which the processor may schedule or deschedule processes as required to achieve effective time sharing between concurrent processes.

It is a further object of the present invention to provide an improved microcomputer in which effective process scheduling is achieved together with message synchronisation between different processes.

It is an object of the present invention to provide an improved microcomputer in which such message synchronisation is achieved between concurrent processes executed by the same microcomputer.

It is a further object of the present invention to provide effective time sharing between different processes where synchronisation is achieved between concurrent processes executed by different microcomputers.

It is a further object of the present invention to provide an improved network of microcomputers in which processor time is shared between a plurality of concurrent processes.

#### SUMMARY OF THE PRESENT INVENTION

The present invention provides a microcomputer comprising memory and a processor arranged to execute a plurality of concurrent processes in accordance with a plurality of program steps, said program steps consisting of a plurality of instructions for sequential execution by the processor, each instruction including a set of function bits which designate a required function to be executed by the processor. wherein (a) said processor comprises (i) a plurality of registers and data transfer means for use in data transfers to and from said register, (ii) means for receiving each instruction and loading into one of the processor registers a value associated with that instruction, and (iii) control means for controlling said data transfer means and registers in response to said function bits to cause the processor to operate in accordance with said function bits. (b) the microcomputer includes scheduling means comprising: (i) means for indicating the current process which is being executed by the processor, (ii) means for identifying one or more processes which form a collection awaiting execution by the processor, (iii) means for adding to the said collection one or more further processes,

(iv) next processor indicator means to indicate the next process in said collection to be executed by the processor, and (v) a program stage indicator for each concurrent process, (c) the process being arranged to respond to selected instruction to terminate execution of the said current process by the processor and to respond to the said expression indicator means to make the process indicated the current process, whereby the processor is operated to share its processing time between a plurality of concurrent processes.

Preferably said memory provides for each process a workspace having a plurality of addressable locations for recording variables associated with the process, and in which one of said processor registers is arranged to hold a workspace pointer value identifying an address of the workspace of the current process. Said processor may be arranged to respond to an instruction to cease executing a current process by replacing the workspace pointer value in said one of the processor registers by the workspace pointer value of a further process in said collection.

Preferably the workspace of each process may include means for indicating the program stage for that process when the process next becomes the said current process.

The invention provides a microcomputer comprising memory and a processor arranged to execute a plurality of concurrent processes in accordance with a plurality of program steps, said program steps consisting of a plurality of instructions for sequential execution by the processor, each instruction including a set of function bits which designate a required function to be executed by the processor wherein (a) said processor comprises: (i) a plurality of registers and data transfer means for use in data transfers to and from said registers (ii) means for receiving each instruction and loading into one of the processor registers a value asso lated with that instruction

and (iii) control means for controlling said data transfer means and registers in response to said function bits to cause the processor to operate in accordance with said function bits. (b) the microcomputer includes scheduling means comprising (i) means for forming a link list of processes awaiting execution by the processor (ii) means for indicating the current process which is currently executed by the processor, and (iii) means for indicating the last process on the list of processes awaiting execution, (c) said memory provides for each process a workspace having a plurality of addressable locations, each said workspace providing (i) memory locations for recording variables associated with the process (ii) a program stage indicator for the process (iii) next process indicator means for use when the process is on said list for indicating the next process on the list and (d) the processor is arranged to respond to selected instructions to stop execution of the said current process by the processor and to make the next process on the list the current process, and to add a further process to the end of the list when required, whereby the processor is operated to share its processing time between a plurality of concurrent processes.

The invention also provides a network of interconnected microcomputers.

Preferably each microcomputer has communication links connected to a further microcomputer in the network by a connection dedicated solely to message transmission between the two interconnected microcomputers, the processor of each microcomputer being arranged to effect message synchronisation between microcomputers and to effect message synchronisation between microcomputers and to terminate execution of current processes and add further processes to said collection in accordance with the synchronisation effected.

The invention also provides a method of operating a microcomputer wherein processes awaiting execution by the processor are identified and added to a collection or removed therefrom by execution by the processor and termination of said execution, whereby the processor shares its time between a plurality of concurrent processes.

The invention further provides a method of operating a network of interconnected microcomputers wherein each microcomputer is arranged to effect message synchronisation between processes on interconnected microcomputers and to schedule and deschedule processes on each microcomputer in accordance with said synchronisation.

It will be understood that the term microcomputer relates to small size computers generally based on integrated circuit devices but it does not impose any limit on how small the computer may be.

An example of a microcomputer in accordance with the present invention will now be described by way of example and with reference to the accompanying drawings.

#### BRIEF DESCRIPTION OF THE DRAWINGS

Figure 1 is a block diagram showing the main features of the microcomputer,

Figure 2 is as more detailed block diagram of some of the components shown in Figure 1 and in particular illustrates more fully the memory and serial links for external communication.

Figure 3 shows further detail in block diagram form of part of the microcomputer and particularly illustrates the registers, data paths and arithmetic logic unit of the central processing unit as well as the interface between the central processing unit and other units of the microcomputer,

Figure 4 illustrates the use of workspaces within the memory,

Figure 5 illustrates schematically a form of instruction used in the microcomputer,

Figure 6 shows in wave form the relative timing and duration of a plurality of timing control signals,

Figure 7 illustrates the generation of timing control signals,

Figure 8 illustrates the operation of the microcomputer of Figures 1 to 3 with variable length operands.

Figures 9a to 9e illustrate successive operations in one manner of communicating using a two word channel between two processes which are executed by the same microcomputer.

Figure 10 illustrates the operation of two communicating processes on one microcomputer,

Figure 11 shows a network of interconnected microcomputers, including detail of the serial link connection between two of them.

Figure 12 illustrates a sequence of operations for effecting communication via serial links between two processes carried out on different microcomputers.

Figures 13<u>a</u> and 13<u>b</u> illustrate the format of data and acknowledge packets for transmission through serial links between two microcomputers,

Figure 14 illustrates the operation of the same two communicating processes of Figure 10 on two interconnected microcomputers,

Figure 15 shows a logic diagram of one output serial link,

Figure 16 shows a logic diagram of one input serial link,

Figure 17 shows the chip formation which may be used for the microcomputer of Figure 1, and

Figure 18 shows an alternative chip formation which may be used for the microcomputer of Figure 1.

## DESCRIPTION OF THE PREFERRED EMBODIMENTS

The microcomputer described herein is an example of a Transputer (Trade Mark of Inmos International plc) microcomputer and comprises a single silicon chip having both a processor and memory as well as links to permit external communication. It is capable of carrying

out a plurality of concurrent processes and effecting scheduling and communication between processes both on the same chip or separate chips. Each microcomputer has at least one K byte of memory in the form of programmable RAM on the same chip as the processor and the processor is capable of obeying programs in the chip's memory. The microcomputer has a plurality of communication links, herein called serial links, to enable it to be connected into a network of interconnected microcomputers so that any one microcomputer can be used as a building block for a network. The communication between any two microcomputers is effected by a serial link which provides one or more specific pin to pin connections each interconnecting two and only two microcomputers. Each link is not shared with other microcomputers or with any external memory. The microcomputer is provided with means for synchronisation in data transmission between microcomputers within the network so that communication through a link between two microcomputers can be initiated by either the receiving or transmitting microcomputer.

The microcomputer contains a program with a plurality of sequential instructions each consisting of two parts, one part representing the function of the instruction and the other part representing data which is loaded into an operand register. In this way the function part of each instruction is of the same bit length regardless of the word length of the processor and in this way uniformity of function format and function bit length is achieved regardless of the word length of the processor. A further important feature of the microcomputer is that its operation is effected by use of a function set which is simple and efficient. The function set consists of a minimum number of functions. The function set includes direct functions which cause the processor to carry out an operation on the contents of the operand register. In a preferred arrangement it also includes one indirect function and two prefixing functions. The use of the indirect function allows a large number of processor

operations to be used without increasing the number and size of data registers to perform the operations. Furthermore the use of a prefixing function provides for variable length operands.

By use of a microcomputer in accordance with this example, any required network of microcomputers can be formed by interlinking a number of microcomputers and the resulting network operates in the same way as any single microcomputer.

# GENERAL DESCRIPTION OF THE STRUCTURE

The main elements of the microcomputer are illustrated in Figure 1 on a single silicon chip 11 using p-well complementary MOS technology. which will be described in more detail with reference to Figure 17. The components provided on the chip have been indicated in block form in Figure 1 although it will be appreciated that the blocks are not intended to represent the relative size and positioning of the various components. On the chip there is provided a central processing unit (CPU) 12 which includes some read-only memory (ROM) 13. The CPU 12 is coupled to a memory interface 14 controlled by interface control logic 15. The CPU 12 incorporates an arithmetic logic unit (ALU), registers and data paths which will be described in more detail with reference to Figure 3. The CPU 12 and memory interface 14 are connected to a bus 16 which provides interconnection between the elements on the chip 11. A service system 17 is provided with a plurality of input pins 18 including a zero volt supply, a 5 volt supply, a reset pin which may be activated to reset the microcomputer to a defined state, and a clock pin 28. The microcomputer is provided with a substantial amount of memory on the chip 11 and this is represented by a random-access memory RAM 19 and the ROM 20. The amount of memory on the chip should not be less than 1 K byte so as to provide sufficient memory capacity to allow the processor 12 to be operated without external memory. Preferably the

memory on the chip is at least 4 K bytes. The division between RAM and ROM on the chip may be selected to suit the particular requirements for the microcomputer. The memory also includes redundancy 21 (this may be as described in our US Patent No 4346459 or US Serial No 194613 or UK Patent Application No 8231055) This region 21 of memory has rows and columns selectively connectable by fuses as shown to replace defective regions of the memory 19 or 20 and thereby increase the production yield of chips which are satisfactory for use. The operation of the microcomputer includes timing control responsive to clock pulses from the pin 28. An external memory interface 23 is provided and connected to a plurality of pins 24 for connection to an optional external memory (not shown). In order to allow the microcomputer to be linked to other similar microcomputers to form a network, a plurality of serial links 25 are provided and in this example four are shown. Each serial link 25 has an input pin 26 and an output pin 27 each of which can be used to form a single pin to pin connection to corresponding output and input pins respectively of a further microcomputer. link is connected to a synchronisation logic unit 10 comprising process scheduling logic which will be described in more detail below. Although the drawings show four serial links 25, three links. or even two links, may be used to form a single network but preferably at least six, and for example seven, such links are provided so that they may be fully interconnected in any desired array.

# GENERAL DESCRIPTION OF USE OF CHIP MEMORY AND COMMUNICATION CHANNELS AND LINKS

Figure 2 shows some of the elements of the microcomputer in more detail and in particular it illustrates the use of the memory on the chip. The microcomputer may be used to carry out a plurality of concurrent processes on the same chip and in Figure 2 the operation

of three concurrent processes have been shown. The memory is used to store the program 30 which may be stored in either ROM 20 or RAM 19. In this particular example the microcomputer is a 16 bit word device although it will be understood that other word lengths may be used. The program 30 consists of a sequence of instructions which in this example are each of 8 bit length and this instruction length may remain the same even if the processor is of word length other than 16 bits. Each instruction is of the format shown in Figure 5 where the most significant 4 bits represent the function of the instruction and the least significant 4 bits represent data. The program 30 incorporates no data other than that held in the designated part of each instruction. The manner in which the processor responds to each function and the way in which the data is handled depend on the particular function selected from a set of functions which will be described below, but the format of the function and data parts of each instruction is always the same. The memory also stores data 31 which may be stored in either the ROM 20 or RAM 19.

The microcomputer carries out a number of processes together, sharing its time between them. Processes which are carried out together are called concurrent processes. At any time, only one of the processes is actually being executed by the microcomputer and this process is called the current process. Each concurrent process to be effected by the microcomputer uses a region of memory called a workspace for holding the local variables and temporary values manipulated by the process. The address of the first local variable of each workspace is indicated by a workspace pointer (WPTR). Similarly for each concurrent process, an instruction pointer (IPTR) is used to indicate the next instruction to be executed from the sequence of instructions in the program relating to that particular process. In Figure 2. which shows three concurrent processes, the workspace for process 1 is indicated by the numeral 32 and the corresponding workspaces for processes 2 and 3 have been marked 33 and 34. Each workspace consists of a plurality of addressable word locations and one word location 35 of each workspace is used to store the workspace pointer (WPTR) of the next process to be executed on a list of processes

waiting to be executed. Thus, a linked list is formed in memory containing pointers to a sequence of workspaces for processes to be executed. If the processor is working on process 1 (see Figure 2) and reaches a point where it is instructed that for the time being it is to stop executing that process, the CPU 12 will begin work on the next process, e.g. process 2. It will be directed to that next process by reading the workspace pointer in memory at location 35. In the preferred embodiment there is a known relationship between workspace pointer for any process and the address of the workspace pointer of the next process on the linked list, so that the next part of the linked list will be easily available from the current process workspace. For each process workspace, a further word location 36 stores the instruction pointer (IPTR) for that process. It will be appreciated that although workspaces for only three processes are shown in Figure 2, the number may be varied depending on the number of concurrent processes to be carried out.

In order to allow communication between different processes carried out by the same microcomputer, a plurality of communication channels indicated by the numerals 40, 41, 42 and 43 are provided in the RAM section 19 of the memory. In this example each communication channel consists of two word locations in memory, one for use in identifying the process wishing to use the channel and the second for holding the data to be communicated through the channel. The operation of these channels will be described more fully with reference to Figures 9a-9e. Figure 2 also shows in more detail the formation of one serial link 25. It is to be understood that each of the serial links is similarly formed. As indicated, the link 25 incorporates two channels 45 and 46 each forming a uni-directional communication channel. In this way the channel 45 is used as an input channel and the channel 46 as an output channel. Each channel consists of two registers each addressable in a manner similar to the two word locations of each of the channels 40 to 43. The two registers consist of a process register 47 used to indicate the process

involved in the communication and a data register 48 for holding the data to be transmitted. The data register 48 in the input channel is connected to pin 26 and the data register 48 in the output channel is connected to pin 27. The operation of the two registers 47 and 48 is controlled by control logic 50 coupled to the synchronisation unit 10. The operation of the serial links, control logic 50 and unit 10 will be described in more detail with reference to Figures 12 to 16.

The RAM section 19 of the memory is used to provide the workspaces 32 to 34 as well as the communication channels 40 to 43 and it may also be used for holding the program and data if required. The ROM 20 may be used for a variety of purposes such as for example holding an interpreter for a high level programming language or for storing "look-up" tables for standard operations. It may also be used to hold control programs for peripheral devices where the microcomputer is intended for a specific purpose.

#### CPU DATA PATHS AND REGISTERS

The central processing unit 12 and its operation will be more fully understood with reference to Figure 3.

The CPU 12 includes an arithmetic logic unit (ALU) 55 and a plurality of data registers connected to three data buses, X bus, Y bus and Z bus. The operation of the registers and their interconnections with the buses is controlled by a plurality of switches diagrammatically represented by the reference numeral 56 and controlled by signals derived from a micro-instruction program contained in the ROM 13. It will be understood that these are switch means integrally formed in the chip construction. Communication between the CPU and the memory (19, 20, 21) is effected via a unidirectional address path 61 leading to the memory interface 14 and a bidirectional data bus 62 also connected to the interface 14. The registers, buses 61 and 62, and the X, Y and Z buses are connected as shown in Figure 3. The registers are as follows:

Abbreviation	Register
MADDR	Memory address register 60 containing the address of the memory location required. $ \label{eq:memory} % \begin{subarray}{ll} \end{subarray} % \b$
IB	Instruction buffer 63 for receiving sequentially from memory instructions of the form shown in Figure 5.
OREGTR	An operand register 65 for receiving the data derived from an instruction in the instruction buffer 63.
IPTR REG	A register 67 which holds the instruction pointer (IPTR) of the current process.
DATA OUT	A register 70 for supplying data to the memory on the data bus $62.$
AREGTR	A first (A) register 71 for holding an operand for th ALU 55.
BREGTR	A second (B) register 72 arranged as a stack with the AREG for holding operands for the ALU 55.
WPTR REG	A register 73 for holding the workspace pointer (WPTR) of the current process.
LPTR REG	A register 74 for holding a pointer to the workspace of the last process on the list of processes waiting to be executed.

As shown in Figure 3, an incrementer 66 and a byte aligner 69 are also provided.

The data bus 62 is provided with a switch 75 operable to precharge the data bus line 62. The X and Y buses are respectively provided with similar switches 76 and 77 operable to precharge the X and Y buses. A further switch 78 is provided between the X and Y buses and is operable to cause signals on the two buses to merge.

The arithmetic logic unit 55 receives inputs from both the X and Y buses and is arranged to output to the Z bus. It provides a further output 8 to the micro-instruction program ROM 13, through a condition multiplexor 9, so as to control the operation of the data path in dependence on the output of the ALU 55.

The instruction buffer 63 is arranged to receive from the memory (19, 20, 21) via interface 14 and bus 62 a sequence of 8 bit words, herein called instructions, each of which has the format shown in Figure 5 and consists of two parts. One part represents a "function" selected from the function set described below and the other part represents data. The instruction buffer 63 provides an output to a decoder 64 which separates the instruction into the function and data halves. The data half is loaded into the operand register 65 and the function half is decoded to provide an address to a micro-instruction register (MIR) 80. The identical procedure is followed for all instructions, regardless of function selected. Each instruction received by the instruction buffer 63 loads into the MIR 80 an address which causes the micro-instruction program in the ROM 13 to execute one or more micro-instructions controlling the switches 56 and interface control logic 15 so that at the end of each sequence of micro-instructions. an operation has been effected by the registers, control logic 15, and data paths of Figure 3 corresponding to the selected function in

the instruction. The operation of the micro-instruction program will be described more fully below.

All the registers shown in Figure 3 apart from the instruction buffer 63 and the micro-instruction register 80 are 16 bit registers. It will be appreciated that in this example in which the processor is a 16 bit word processor, each 16 bit word location in the program contains two instructions, as each instruction is only 8 bits long. It is therefore necessary for the instruction pointer, which is held in the register 67 to be capable of pointing to a specific 8 bit byte in order to identify a single instruction from a program word location which incorporates two instructions. For this reason the program 30 (Figure 2), in this example, is written into the bottom half only of the memory 19. In this example the memory has 64K words and consequently the program 30 is written into locations 0 to 32767 as the addresses of these locations can be represented by 15 bits only. This leaves an additional bit in the instruction pointer which can be used to identify which of the two bytes at each word address is necessary in order to identify a specific instruction. The micro-instruction ROM 13 contains 122 words, each of 68 bits. Each row of the ROM 13 contains 68 bits so that the ROM is arranged to provide 68 output signals at any time. The operation of the micro-instruction program will be described more fully below.

As can be seen from Figure 3, the interface logic controller 15 is provided with a plurality of single bit state latches which are used to record the state of the memory interface. A latch 110, called a running latch, defines the source of instructions to be executed. If the latch 110 has state 1 the source of instructions is memory (this may be an external memory via the interface 23 if desired). If the latch has state 0, the source of instructions is one of the serial links 25 to allow instructions to be received from an external source. It may be necessary to go repeatedly to the same serial link 25 for two or more successive instructions whereas when the

instructions are derived from memory, the instruction pointer IPTR is advanced for each instruction. An IB latch 112 records the state of the IB register 63. An MADDR latch 113 records the state of the MADDR register. A MEM ENABLE latch 114 records the state of the memory interface and has state 1 whenever the memory interface 14 is occupied. A WRITE latch 115 records that a write request has been made to the memory. The BYTE latch 116 records that a byte request has been made to the memory. An UPPER/LOWER latch 117 holds the least significant bit of byte addresses and is loaded from the least significant bit of the A register 71 when the content of the A register is shifted one place to the right.

#### FUNCTION SET

The function elements of the instructions which are received by the instruction buffer 63 are determined by the function set for the microcomputer. The function set is the list of available functions which can be selected when writing a program and to which the microcomputer is capable of responding.

There are three types of function in the function set.

Direct functions which use the contents of the operand register 65 as data (the contents of other registers may also be used as data).

Indirect function which use the contents of the operand register 65 to select one of a variety of "operations" using data in registers other than the operand register 65. The selectable "operations" are listed below the function set.

Prefixing functions which accumulate operands into the operand register 65.

The function set is as follows:

# FUNCTIONS

	Code No	Abbreviation	Name	
			Direct Functions	
	0	, 1 dw	load from workspace	
	1	stw	store to workspace	
	2	ldpw	load pointer into workspace	
	3	ldwi	load from workspace and increment	
	4	1 dv	load from vector	
	5	stv	store to vector	
	6	141	load literal	
	7	adl	add literal	
	8	j	jump	
	9	. jnz	jump non zero	
	10	1 dpc	load pointer into code	
	11	call	call procedure	
INDIRECT FUNCTIONS				
	13	opr ·	operate	
			• •	
			PREFIXING FUNCTIONS	
	•			
	14	pfix	prefix	
	15	nfix	negative prefix	

The operations which may be effected by use of indirect functions are as follows:

#### OPERATIONS

Code No	Abbreviation	Name
0	rev	reverse
1	. eqz	equal to zero
2	gt	greater
3	and	and
4	or	or
5	xor	exclusive or
6	add	add
7	sub	subtract
8	run	run process
. 9	pse	pause
10	join	join
11	sync	sychronise
12	ret	return
13	rot	rotate bytes
14	sr ·	shift right
15	s1	shift left

Prior to describing these functions and operations, the notation which is used herein will be set forth. The Transputer microcomputer is used preferably with OCCAM (Trade Mark of Immos International plc) language, which is set forth more particularly in the booklet entitled <a href="Programming Manual-OCCAM">Programming Manual-OCCAM</a> published and distributed by Immos Limited in 1983 in the United Kingdom, as well as Taylor and Wilson, "Process - Oriented Language Meets Demands of Distributed Processing", <a href="Electronics">Electronics</a> (Nov. 31, 1982), both of which are hereby incorporated herein by reference. OCCAM language is particularly well suited to concurrent processing. Because the preferred embodiment is particularly suitable for concurrent processing, the use of OCCAM language with the present example is quite appropriate.

Other languages can be used with an appropriate compiler. In actual application, the programmer will write a program using OCCAM language and a compiler will convert this to particular instructions in customary fashion. Nevertheless, the functions and operations in the instructions are susceptible of description using OCCAM language to show what happens within the preferred embodiment of the microcomputer described herein. Thus, in describing these functions and operations, as well as examples of use, the following notation will be used:

#### NOTATION

#### 1 PROCESS

A process starts, performs a number of actions, and then terminates. Each action may be an assignment, an input or an output. An assignment changes the value of a variable, an input receives a value from a channel, and an output sends a value to a channel.

At any time between its start and termination, a process may be ready to communicate on one or more of its channels. Each channel provides a one way connection between two concurrent processes; one of the processes may only output to the channel, and the other may only input from it.

An assignment is indicated by the symbol ":=". An assignment

v := e

sets the value of the variable v to the value of the expression e and then terminates. For example, x:=0 sets x to zero, and x:=x+1 increases the value of x by 1.

An input is indicated by the symbol "?". An input

inputs a value from the channel "c", assigns it to the variable  $\boldsymbol{x}$  and then terminates. An input

c ? ANY

inputs a value from the channel "c", and discards the value.

An output is indicated by the symbol "!". An output

c!e

outputs the value of the expression e to the channel "c" and then terminates. An output

c ! ANY

outputs an arbitrary value to the channel "c".

The process SKIP terminates with no effect.

#### 2. CONSTRUCT

A number of processes may be combined to form a sequential, parallel, conditional or alternative construct. A construct is itself a process, and may be used as a component of another construct. Each component process of a construct is written two spaces further from the left hand margin, to indicate that it is part of the construct.

A sequential construct is represented by

SEQ

P1

P2

Р3

The component processes Pl, P2, P3 ... are executed one after another. Each component process starts after the previous one terminates and the construct terminates after the last component process terminates. For example

SEQ
in ? x
x := x + 1
out ! x

inputs a value, adds one to it, and then outputs the result.

A parallel construct is represented by

PAR P1 P2 P3

The component processes P1, P2, P3 ... are executed together, and are called concurrent processes. The construct terminates after all of the component processes have terminated. For example,

PAR in?x

allows an input to x and output from y to take place together.

Concurrent processes communicate using channels. When an input from a channel "c", and an output to the same channel "c" are executed together, communication takes place when both the input and the output are ready. The value is assigned from the outputting process to the inputting concurrent process, and execution of both concurrent processes then continues.

#### A conditional construct

```
IF
condition 1
P1
condition 2
P2
condition 3
P3
```

means that process P1 is executed if condition 1 is true, otherwise process P2 is executed if condition 2 is true, and so on. Only one of the processes is executed, and the construct then terminates. For example

```
IF
    x >= 0
    y := y+1
x < 0
    SKIP</pre>
```

increases y only if the value of x is positive.

#### An alternative construct

ALT
input 1
P1
input 2
P2
input 3
P3

waits until one of input 1, input 2 ... is ready. If input 1 first becomes ready, input 1 is performed, and then process P1 is executed. Similarly, if input 2 first becomes ready, input 2 is performed, and then process P2 is executed. Only one of the inputs is performed, and then the corresponding process is executed and the construct terminates. For example:

ALT
count? ANY
counter := counter + 1
total ? ANY
SEQ
out ! counter
counter :=0

either inputs a signal from the channel "count", and increases the variable "counter" by 1, or alternatively inputs from the channel "total", and outputs the current value of the variable "counter", and resets it to Zero.

3. REPETITION
WHILE condition

repeatedly executes the process  ${\bf P}$  until the value of the condition is false. For example

WHILE x > 5 x := x - 5

decreases x by 5 until its value is less than 5.

A variable is either a simple variation, corresponding to a single word in store, or is one of a numbered set of variables called a vector. For example, v [3] := 0 sets the value of variable number 3 in the vector v to 0, and v[0] + 1 increases the value of variable number 0 by 1.

-25-

A variable is introduced by a declaration such as

VAR v :

which introduces v for use in the process P.

#### 5. PROCEDURES

A procedure definition allows a process to be given a name. For example

PROC square ( n, sqr ) · sqr := n \* n

defines the procedure "square".

The procedure name may be used as an abbreviation for the process. For example

square ( x, sqrx )

means

sqrx := x \* x

#### EXPRESSIONS

An expression is constructed from operators, variables, numbers, the truth values TRUE and FALSE and the brackets { and }.

TRUE is a value consisting entirely of 1 bits, and FALSE is a value consisting entirely of 0 bits.

The operators \*, -, \*, / represent addition subtraction, multiplication and division as usual.

For the operators =, <>, > and <=, the result is produced as shown below:

x = y true if x is equal to y  $x \Leftrightarrow y$  true if x is not equal to y x > y true if x is greater than y  $x \leqslant y$  true if x is less than or equal to y

For the operators \/, /\ and ><, each bit of the result is produced from the corresponding bits of the operands according to the following table:

X	У	x \ / y ·	x /\y	x >< y
0	0	0	0	0
0	1	1	0	1
1	0	1	0	1.
1	1	1	1	0

For the NOT operator, each bit of the result is produced from the corresponding bit of the operand, according to the following table:

x NOT x 0 1 1 0

For the operators << and >>

- x << y is the value of x moved y bits to the left, vacated bit positions being filled with 0 bits
- x >> y the value of x moved y bits to the right vacated bit positions being filed with 0 bits

The above general OCCAM language notation will now be applied to the microcomputer of the example.

The register variables are defined as follows:

IPTR represents the contents of the instruction pointer register 67

WPTR represents the contents of the workspace pointer register 73  $_{\odot}$ 

LPTR represents the contents of the list pointer register 74 AREG represents the contents of the A register 71 BREG represents the contents of the B register 72 OREG represents the contents of the operand redister 65

A transfer from one register to another is represented by an assignment, eg:

BREG := AREG

which means that the contents of the A register is copied to the B register, replacing the previous contents of the B register.

The memory in the transputer is represented by a vector:

An individual word in memory is identified by subscripting the vector eg:

memory [ AREG ]

which means the contents of the word in memory whose address is the contents of the A register.

A transfer between memory and a register is similarly represented by an assignment eg:

memory [ AREG ] := WPTR

which means that the contents of the word in memory whose address is the contents of the A register is replaced by the contents of the workspace pointer register. Three procedures (PROC) "run", "wait" and "moveto" occur frequently in the following description. They are defined as follows, wherein link [process] represents the contents of the process register 47 of a serial link 25 and NIL represents a special value which is not the workspace pointer of any process. READY represents a further special value used by the serial links:-

```
PROC run (w)
1
           1F
             w <> READY
                SEO
                  memory [ LPTR - 2] := W
                  LPTR := W
             w = READY
                SK IP
         PROC wait
2
           SE0
             memory [ WPTR - 1 ] := IPTR
3
             for each external request from a serial link
               SEO
                run ( link [ process ] )
                 link [ process ] := NIL
             WPTR := memory [ WPTR - 2 ]
              IPTR := memory [ WPTR - 1 ]
         PROC moveto (w)
1
            SEQ
2
3
              ΙF
                WPTR = LPTR
                  LPTR := W
                WPTR <> LPTR
                  memory [ w - 2 ] := memory [ WPTR - 2 ]
              WPTR := W
```

In the above procedures, line numbers have been added for reference purposes in explanation which will be given below.

# Function and Operation Definitions

These are now set out below using the notation defined above.

# load from workspace

Definition:

SEQ

BREG := AREG

AREG := memory [ WPTR + OREG ]

Purpose:

to load the value of a location in the current process workspace.

#### store to workspace

Definition:

SEO

memory [ WPTR + OREG ] := AREG

AREG := BREG

Purpose:

to store a value in a location in the current process workspace.

# load pointer into workspace

Definition:

SEQ

BREG := AREG

AREG := WPTR + OREG

Purpose:

to load a pointer to a location in the current process workspace

to load a pointer to the first location of a vector of locations in the current process workspace.

# load from workspace and increment

Definition:

SEO

BREG := AREG

AREG := memory [ WPTR + OREG ]
memory [ WPTR + OREG ] := AREG + 1

Purpose:

to load the value of a location in the current process workspace, and increment the location

to facilitate the use of workspace locations as loop counters, incrementing towards zero

to facilitate the use of workspace locations as incrementing pointers to vectors of words or bytes.

load from vector

Definition:

AREG := memory [ AREG + OREG ]

Purpose:

to load a value from an outer workspace

-31-

to load a value from a vector of values

to load a value, using a value as a pointer (indirection) – in this case OREG = 0

#### store to vector

Definition:

SE0

memory [ BREG + OREG ] := AREG

AREG := BREG

Purpose:

to store a value in a location in an outer workspace

to store a value in a vector of values

to store a value, using a value as a pointer (indirection) – in this case  $\mbox{OREG} = 0$ 

#### load literal

Definition:

SE0

BREG := AREG

AREG := OREG

Purpose:

to load a value

## add literal

Definition:

AREG := AREG + OREG

Purpose:

to add a value

to load a pointer to a location in an outer workspace

to load a pointer to a location in a vector of values

jump

Definition:

IPTR := IPTR + OREG

Purpose:

to transfer control forward or backwards, providing loops, exits from loops, continuation after conditional sections of program

jump non zero

Definition:

IF

AREG <> 0

IPTR := IPTR + OREG

AREG = 0 SKIP

Purpose:

to transfer control forwards or backwards only if a non-zero value is loaded, providing conditional execution of sections of program and conditional loop exits

to facilitate comparison of a value against a set of values

## load pointer into code

Purpose:

SE0 Definition:

BREG := AREG

AREG := IPTR + OREG

to load into the A register the

address of an instruction to load the address of a vector of data forming part of the program

call procedure

Definition: SEQ

memory [ WPTR - 1 ] := IPTR

IPTR := AREG

AREG := WPTR

moveto (WPTR + OREG )

to provide an efficient procedure Purpose:

call mechanism

to facilitate code sharing, where two identical procedures are executed on the same processor

Indirect Functions

operate

Definition: operate (OREG)

perform an operation, using the Purpose:

> contents of the operand register (OREG) as the code defining the

operation required.

# **Prefixing Functions**

#### prefix

Definition:

OREG := OREG << 4

Purpose:

to allow instruction operands which are not in the range 0 - 15 to be represented using one or more prefix instructions

negative prefix

Definition:

OREG := (NOT OREG) << 4

Purpose:

to allow negative operands to be represented using a single negative prefix instruction followed by zero or more prefix instructions.

## Operations

#### reverse

Definition:

SEO

OREG := AREG

AREG := BREG

BREG := OREG

Purpose:

to exchange the contents of the A

and B registers

to reverse operands of asymmetric operators, where this cannot conveniently be done in a compiler

## equal to zero

Definition:

IF

AREG = 0

AREG := TRUE

AREG <> 0

AREG := FALSE

Purpose:

to test that A holds a non zero value

to implement logical (but not bitwise) negation

to implement

A = 0

as eqz

A <> 0 as eqz, eqz

if A = 0 ... as jnz

if A <> 0 ... as eqz, jnz

## greater

Definition:

IF

BREG > AREG

AREG := TRUE

BREG < = AREG

AREG := FALSE

Purpose:

to compare A and B (treating them as twos complement integers), loading -1 (true) if B is greater than A, O (false) otherwise

to implement B < A by reversing operands

to implement  $B \leftarrow A$  as (gt, eqz), and B >= A by reversing operands and (gt, eqz)

and

Definition:

AREG := AREG / \ BREG

Purpose:.

to load the bitwise AND of A and B, setting each bit to 1 if the corresponding bits in both A and B are set to 1, O otherwise

to logically AND two truth values

or

.... Definition: \_\_

AREG := BREG \ / AREG

Purpose:

to load the bitwise OR of A and B, setting each bit to 1 if either of the corresponding bits of A and B is set, O otherwise

to logically OR two truth values

exclusive or

Definition:

AREG := BREG >< AREG

Purpose:

to load the bitwise exclusive OR of A and B setting each bit to 1 if the corresponding bits of A and B are different, O otherwise

to implement bitwise not as (ldl -1, xor)

add

Definition: AR

AREG := BREG + AREG

Purpose: .

to load the sum of B and A

to compute addresses of words or

bytes in vectors

subtract

Definition: AREG := BREG - AREG

Purpose: to subtract A from B, loading the

result

to implement

A = B as sub, eqz

 $A \Leftrightarrow B$  as sub, eqz, eqz if A = B as sub, jnz,..

if A <> B as sub, eqz, jnz,...

run process

Definition: SEQ

memory [ AREG - 1 ] := BREG

run ( AREG )

Purpose: to add a process to the end of the

active process list

## pause

Definition:

SEQ

run ( WPTR ) wait ( )

Purpose:

to temporarily stop executing the

current process

to share the processor time between the processes currently on the

active process list

## join

Definition:

IF

memory [ AREG ] = 0

moveto ( memory [ AREG + 1 ] )

memory [ AREG ]  $\Leftrightarrow$  0

SEQ

memory [ AREG ] : = memory [ AREG ] - 1

wait ( )

Purpose:

to join two parallel processes; two words are used, one being a counter, the other a pointer to a workspace. When the count reaches 0, the workspace is changed

## synchronise

Definition:

ΙF

memory [ AREG ] = NIL

SE0

memory [ AREG ] := WPTR

wait ( )

memory [ AREG ] <> NIL

SEQ

run ( memory [ AREG ] ) memory [ AREG ] := NIL

Purpose:

to allow two processes to

synchronise and communicate using a

channe1

return

Definition:

SEQ

moveto ( AREG )

IPTR := memory ['WPTR - 1 ]

AREG := BREG

Purpose:

to return from a called procedure

rotate bytes

Definition: AREG := (AREG << 8) \/ (AREG >> (bitsperword - 8))

Purpose:

to rotate the bytes in the A register to allow 8 bit byte values to be combined

to form a single word value

to allow a word value to be split into several

component 8 bit values

## shift right

Definition:

AREG := AREG >> 1

Purpose:

to shift the contents of the A

register one place right

## shift left

Definition:

AREG := AREG << 1

Purpose:

to shift the contents of the  $\mbox{\bf A}$ 

register one place left

It will be seen that the above function set includes direct functions, indirect functions and prefixing functions. At the start of execution of any instruction, regardless of the function selected for that instruction, the predetermined set of bit positions in the instruction buffer 63 which receive the function part of the instruction are used to provide an input to the decoder 64 whereas the other predetermined bit positions in the instruction buffer 63 which represent the data part of each instruction are used to load the least significant four bit positions of the operand register 65. If the function is a direct function, the processor then acts in accordance with the selected function on the contents of the operand register 65. If the function is an indirect function, the contents of the operand register 65 are used to determine the nature of the operation to be carried out and the operation is effected on data held in other registers. At the end of any instruction in which the function is direct or indirect, the operand register 65 is cleared to zero. If the function is a prefix function, the processor operates to transfer existing data in the operand register 65 to positions of higher significance and then load into the vacated positions of lower significance data derived from the data part of the instruction.

At the start of each instruction, the instruction pointer is incremented. Consequently the instruction pointer always points to the next instruction to be executed.

The operand register 65 is used for several different purposes. The "data" which it receives with each instruction may be a literal value for use in a computation or in the case of an indirect function, it is the definition of the required operation. A further important use is that for some functions, the data value in the operand register 65 will be combined with the data in the workspace pointer register 73 to locate an address where the value of a particular variable is to be found or to be stored. For example, the workspace pointer register 73 will contain the workspace pointer WPTR of the current process. This points to a reference memory address for the workspace. Variables or other pointers will be defined and stored in that workspace at address locations which are offset by known amounts from the address pointed to by the workspace pointer WPTR. That offset will generally be specified by an instruction portion and stored in operand register 65. Indeed, the load and store from workspace instructions will implicitly refer to a memory location defined by the combination (illustratively the additive sum) of the contents of WPTR register 73 and the operand register 65. Furthermore, the contents of the operand register 65 will be combined with the contents of other registers such as the A register 71 or the IPTR register 67, for accessing vectors or for branching in the program. Examples of this will be given below.

It will be seen that the direct functions are selected to cover the most commonly required actions within the microcomputer in order to maximise efficiency of operation. By using 4 bits to represent the function element of each instruction, the function set uses codes 0 to 15 although no function has been allocated to code 12. Code 13 is used to indicate the indirect function which in this case is the "operate" function causing the least significant 4 bits of the instruction to be loaded into the operand register 65 in the usual

way but the contents of that operand register are then used by the processor to determine an operation on data held in other registers. It will be appreciated that in this way the number of operations can be extended whilst maintaining uniformity of an 8 bit instruction. By use of the prefix or negative prefix functions before the "operate" instruction, the contents of the operand register 65 can be varied to provide a much greater selection of operations than is set out above. The use of pfix and nfix will be described in more detail below with reference to Figure 8 but first it is necessary to describe further the operation of the micro-instruction program 13.

The micro-instruction program is the means of generating control signals which control the switches 56 and inferface control logic 15 (Figure 3) in order to carry out the required "function" of each sequential instruction arriving in the instruction buffer 63 from the microcomputer program. The micro-instruction program consists of a list of micro-instructions stored in rows and columns in the ROM 13. The ROM 13 provides an output, called a micro-word, which may consist of 68 bits each providing a control signal and divided up into a plurality of different fields, each field consisting of a predetermined group of bit positions. The output at any one time is provided at selected bit positions depending on the micro-instruction selected. Each field may relate to a specific area of control. such as for example, one field controls which register is connected to the X bus , another field controls which register is connected to the Ybus, another field controls which register is connected to the Z bus, another field controls the action of the ALU 55 and another field controls feed back signals to the multiplexor 9 and MIR 80. One field controls the interface control logic 15 and provides micro-instruction output signals such as "Read", "Write" and "Next instruction required (NEXT)" to allow the microprogram to control communication between registers and the memory 19 through the interface 14.

The particular micro-instruction selected in the ROM 13 depends on the address in the MIR 80, which is a 7 bit register providing a row and column selection in the ROM 13. At the beginning of each instruction received by the instruction buffer 63 the "function" is decoded by the decoder 64 and is passed through the condition multiplexor 9 to provide an address for selection of the micro-instruction in the ROM 13. Some functions may require only one micro-instruction to carry out the function, in which case the ROM 13 provides a micro-word output dependent on the address decoded by the decoder 64 and the function is completed in one cycle of operation. herein called a minor cycle, of the ROM 13. Other functions require a succession of micro-instructions, and therefore minor cycles. In this case, the decoder 64 provides the MIR 80 with an address for the ROM 13 to select the first micro-instruction necessary for that function. Thereafter the micro program proceeds to execute a sequence of micro-instructions, each taking one minor cycle, and each micro instruction provides in a field of its output micro-word 7 bits for the MIR 80 so as to identify the address of the next micro instruction to be executed in the sequence. The least significant two bits of the MIR 80 may be conditionally set, so that the next minor instruction is selected as a result of conditions produced by a previous minor cycle, and fed back through the multiplexor 9 to effect the address in the MIR 80. This allows the next micro-instruction to be selected from four possible options depending on for example the values in the various registers shown in Figure 3. If the two conditional bits of the MIR 80 are not set conditionally then the next micro-instruction indicated by the address in the MIR 80 is unconditionally executed. When all micro-instructions have been executed in order to achieve operation of the instruction in the instruction buffer 63, the control signal "NEXT" is generated in a field of the micro-word output of the ROM 13. thereby demanding the next instruction from the memory 19 to the

instruction buffer 63.

Each minor cycle consists of two phases, a source phase and a destination phase. The control signals generated from the ROM 13 fall into three groups; those which are active only during the source phase, those which are active only during the destination phase and those which are active throughout the whole minor cycle. In order to control the occurrence and duration of the control signals, the timing control is arranged to provide four different strobe signals indicated in Figure 6. These are a source strobe 150, a destination strobe 151, a column precharge strobe 152 and a micro-instruction strobe 153. The source strobe is a timing signal which allows a register to place its contents onto a bus and its duration is long enough to allow the arithmetic logic unit to form a result. The destination strobe signals are arranged to allow registers to accept data from a bus. The micro-instruction strobe is used to generate the address of the next micro-instruction from the condition multiplexor 9. The column precharge strobe is used to precharge the bus lines X and Y to a high state ready for the next source strobe. The relative timing and duration of these strobes is shown in Figure 6. They are generated by the arrangement shown in Figure 7. The clock pulses from pin 28 (Figure 1) generate a GO signal for the beginning of each minor cycle. This signal is passed through four successive delay units within the CPU 12 so that the micro-instruction strobe 153 is derived from the output of the first delay unit 154, the destination strobe 151 is derived from the output of the second delay unit 155, the column precharge signal 152 is derived from the output of the third delay unit 156 and the source strobe 150 is derived from the output of the fourth delay unit 157. The operation of the processor is therefore synchronised to the external clock input 28.

## USE OF VARIABLE LENGTH OPERANDS

As already explained above, the microcomputer is capable of operating with a variable length operand. Although each instruction allocates 4 bit locations to an operand, it is possible to build up in the operand register 65 an operand up to 16 bits by use of the functions ofix and ofix corresponding to codes 14 and 15 in the function set set out above. This operation can best be understood with reference to Figure 8. This indicates the operand register 65 having four sections each with 4 bits. The arithmetic logic unit 55 is indicated having four sections corresponding to 4 bits of increasing significance and the connection between the O register 65 and the arithmetic logic unit 55 is controlled via a gate 90 selectively controlling transmission through the Y bus to the arithmetic logic unit. The Y and Z buses are each shown separated into four parts. each handling four bits of data of different significance, e.g. Y[3:0] represents the part of the Y bus handling the four digits of least significance whereas Y[15:12] handles the four digits of greatest significance, and similarly for the Z bus. Each section of the operand register 65 other than the least significant 4 bits, can be supplied through a gate 91 from the Z bus or alternatively it can be fed with a zero from the gate 92. The instruction from the instruction buffer 63 in Figure 8 is divided so that the least significant 4 bits are fed to the least significant 4 bit position of the O register 65 and thefunction element is used to select an address in the micro-instruction program 13 as previously described with reference to Figure 3. The truth table of Figure 8 indicates three alternative possibilities where the function corresponds to pfix or nfix or neither. It also lists the corresponding control signals which are fed onto lines 100 to 104 from the micro-word output of the ROM 13, and the duration of those signals.

The micro-word output control signals used in this case are as follows:

- OPD NOT 0 meaning that the operand register 65 is not supplied with zeroes if the truth table has a "1" but is supplied with zeroes if the truth table has a "0".
- NEXT meaning that the operand register 65 will be loaded with the next operand from the instruction buffer 63 if the truth table has a "1" but not if the truth table has a "0".
- 3. Y FROM OPD meaning that the Y bus receives the operand from the operand register 65 if the truth table has a "1" but not if the truth table has a "0".
- 4. Z FROM Y meaning that the Z bus output from the ALU 55 will receive data from the Y bus if the truth table has a "1", but not if the truth table has a "0".
- 5. Z FROM NOT Y meaning that the ALU 55 will cause the signal on the Y bus to be inserted and passed to the Z bus if the truth table has a "1" but not if the truth table has an "0".

The duration of these five control signals in each minor cycle is indicated in Figure 8 wherein S indicates duration in the source phase only, D indicates duration only in the destination phase and S + D indicates duration in both.

The micro-word control signal on line 100 operates the gates 91 and 92 to allow the Z bus to unload into the operand register 65 in response to the functions pfix and nfix whereas any other function causes the three most significant stages of the operand register 65

to be zeroed by an input through the gate 92. All instructions generate the control signal NEXT on the last minor cycle and this is applied to line 101 to cause the operand register 65 to be loaded with the next operand. Line 102 receives the signal "Y FROM OPD" and causes the operand register to be connected through the gate 90 to the Y bus for both pfix and nfix. Line 113 receives the control signal "Z FROM Y" and causes the arithmetic logic unit 55 to transmit to the Z bus the signal on the Y bus for pfix but not for nfix. Line 104 receives "Z FROM NOT Y" and allows the signal on Y to be inverted and supplied through the ALU 55 to the Z bus for nfix but not for ofix. The signals on lines 100, 103 and 104 exist throughout the source and destination phases of each minor cycle whereas the signal on line 101 exists only in the destination phase and the signal on line 102 exists only in the source phase. When the function is pfix, it can be seen that signals corresponding to a truth condition are supplied on lines 100, 101, 102 and 103 and in this way, the 4 bits of operand in the least significant section of the operand register 65 are advanced through the arithmetic logic unit to the next significant stage of the operand register 65 thereby allowing a further 4 bits of operand to be loaded into the least significant positions of the operand register 65. This operation is repeated each time an instruction is derived with pfix function up till a maximum of 16 bits of operand. Similarly if the function is nfix. the process is generally similar in allowing each successive 4 bits of operand to be moved up into a higher stage of the O register 65 without zeroes being written in after each instruction. This allows a negative operand to be built up to a maximum of 16 bits. The truth table indicates that if the function is neither pfix nor nfix, the control signal on line 100 causes zeroes to be fed into the three upper significant stages of the O register 65 (representing bits 15 to 4) at the end of that instruction.

## SCHEDULING OF PROCESSES

As already indicated, the microcomputer may operate a number of concurrent processes. It therefore provides a system of scheduling to determine which process shall be performed at any particular time. At any one time the WPTR register 73 (Figures 3) holds the workspace pointer of the process currently being executed. However the workspace of the current process and the workspaces of other processes waiting to be executed form a list in which one location of each workspace holds the workspace pointer of the next process on the list. Another location in each process workspace holds the instruction pointer identifying the next instruction which is to be carried out for that process when it becomes the current process. Furthermore the LPTR register 74 contains the address of the workspace for the last process currently waiting to be executed. In this way new processes can be added to the end of the list and the LPTR register 74 always indicates the current end of the list. The processor normally executes the processes on the list in sequence only advancing to a subsequent process when the current process executes a "pause" operation (code 9 in the operations list) or when the current process deschedules itself by executing a "join" operation (code 10 in the operations list) or a synchronise operation (code 11 in the operations list). In any of those situations, the current process ceases to carry out further instructions and the processor saves the instruction pointer IPTR in the process workspace as indicated at 36 in Figure 2, and moves onto the next process which has been identified by the address of the next process, shown as 35 in Figure 2 and then loads into the IPTR register 67 the IPTR for the new process. So that there is always at least one process running, a null process is provided and the null process is run when no other process is active.

The procedures "run", "wait", and "moveto" defined above are used in scheduling. A process will be "scheduled" when it is the current process or is on the linked list of processes which are waiting to be executed. A process becomes "descheduled" when it is taken off the linked list. A descheduled process will never be executed unless some other process or instruction schedules it, i.e. adds it to the end of the linked list. It will be recalled that LPTR register 74 (Figure 3) is used to store the workspace pointer for the last process on the list. Hence, it must be adjusted whenever a process is added to the linked list. Also, when a process is to be scheduled, the CPU 12 must be able to determine which instruction is to be executed next for the process. This is done by storing in memory the appropriate instruction pointer IPTR, which is in IPTR register 67 while the process is current. Such storage is done, for example at memory location 36 (Figure 2).

In describing these procedures, it will be convenient to refer to Figure 4 which illustrates workspaces 32 and 33 more particularly, as well as registers 65, 67, 71, 73 and 74. Figure 4 shows representative memory addresses and contents of the workspaces.

The process which has the workspace 32 is made the current process by inserting its workspace pointer WPTR into register 73. In this case, WPTR equals 10000. When the process becomes the current process the processor finds the next instruction to be executed by examining WPTR-1, i.e. the contents at memory location 9999, to find a pointer 84 to an instruction and loads this pointer in the IPTR register 67. While this is the current process, the processor will us the contents of IPTR register 67 to point to the next instruction.

During the processing, it will use variables whose addresses are formed by combining a reference value, such as the WPTR or the contents of the A register 71, and an operand placed in register 65. In a load from workspace operation an operand of "2" will refer to whatever is at memory location 10002 while the process corresponding

to workspace 32 is current. When processing is to stop, the linked list is consulted. Elements 85 and 86 are part of the linked list. The processor will look at WPTR-2 to find MPTR 85 at memory location 999B, pointing to the next workspace. Pointer 85 will contain the number 11000 which points to workspace 33. If the process corresponding to workspace 33 is the last process on the linked list, then LPTR register 74 will contain the pointer 11000. No pointer 86 will be stored at memory location 1099B until some process is added to the linked list.

Turning now to the three procedures, PROC run (w) is used to schedule a process defined by w i.e., add it to the linked list. This procedure has been defined above and reference will now be made to that definition and the line numbers used in the definition.

If the value of w is the special value "READY" no action is performed. Further explanation of this will follow later with reference to communications between different microcomputers. Otherwise w is a pointer to a process workspace, and lines 5 and 6 will be executed in sequence. In line 5, LPTR means the contents of LPTR register 74, which is a pointer to the reference address for the workspace for the last process on the linked list. The memory whose address is LPTR-2 would contain the address of the workspace pointer for the next process, but as yet there is none because LPTR corresponds to the last process. Line 5 now assigns w (the workspace pointer in the process w) to memory location LPTR-2, so process w is now at the end of the linked list. At this point, the contents of LPTR register 74 points not to the last process w, but to the penultimate process. This is corrected in line 6 which enters into LPTR register 74 the workspace pointer for process w. Because of this step, further processes can be added to the linked list without deleting process w unintentionally, which would happen if LPTR register 74 were not updated. With reference to Figure 4, if there are only two processes scheduled, as shown, and process w corresponds to a workspace whose pointer is 12000, PROC run (w) would enter 12000 in memory [10998] and enter 12000 into register 74.

The procedure called "wait" can be used alone or in combination with PROC run (w). By itself, it deschedules the current process and enables the system to execute the next process, executing it where appropriate in its program instead of at its first instruction. Reference will now be made to the previous definition of PROC wait. When procedure "wait" is called (line 1), a sequence is commenced (line 2) having four steps (lines 3, 4, 8 and 9). Lines 4-7 relate to external requests, and discussion of this can be deferred. although link [process] represents the contents of process register 47 of serial link 25 (Figure 2). In line 3, memory [WPTR-1] is the memory space at the address WPTR-1, which is based on the reference address WPTR of the current process. That memory location is, in the preferred embodiment, used to point to the next instruction to be executed when the process is recommenced. The contents of IPTR register 67 always points to the instruction to be executed next for the current process. Hence, line 3 simply stores in memory (preferably on-chip) the pointer to the next instruction to be executed. If the procedure PROC run (w) has preceded PROC wait, then at this time, the current process (w) will have been added at the end of the linked list (by PROC run (w)1, LPTR register 74 will have been updated (also by PROC run (w)), and now the pointer to the next instruction for process w will have been stored at a known location. memory [WPTR-1], with respect to the workspace pointer address (WPTR) for process w. Thus, process w is ready now to be deactivated. Line 8 looks to the linked list for the next process. Its workspace will be pointed to by the contents at address WPTR-2 of the current workspace. Hence, line 8 assigns to WPTR register 73 the workspace pointer for the next process on the linked list. Now the reference address has advance, and the system next finds out what the next instruction is for this process by looking at the pointer stored at the memory whose address is WPTR-1. To use Figure 4, consider that workspace 32 is current and its process receives an instruction which includes PROC wait. Initially, WPTR is 10000. At line 8, register 73 is set to the contents found at memory address 9998, which will be the pointer 11000. At line 9, register 67 is set with

the instruction pointer found at memory address 10999. Thus, if PROC run (w) is followed by PROC wait, the current process is added to the end of the list (its workspace pointer is stored on the linked list), the pointer to its next instruction is stored in memory, it is deactivated, and the next process on the linked list is commenced beginning at the proper instruction. All of this is done using only four registers. This arrangement permits the scheduling and descheduling of processes which are limited in number by only the amount of memory in the system.

The procedure named "moveto" can be used to set the workspace reference pointer to a different address in the workspace for the current process, without necessarily changing to a new IPTR. Thus, if a process has its reference workspace pointer at 10000, moveto (10200) could be used to set the registers to change the reference pointer to 102)) for this same process. This will be described as follows with reference to the previous definition of PROC moveto (w).Line 2 of the definition declares this is a sequence of steps. Lines 3 and 8 are equally offset from the left margin, so they both will be done in sequence. Assume that the system is not on the last process. Hence, line 4 will be false, so the system will jump to line 6. The condition at line 6 will be true, so line 7 will be executed. Line 7 sets the contents at memory address w-2 to the workspace pointer for the next process on the linked list. Next, line 8 changes the contents of the WPTR register 73 to the value w. Now register 73 points to a new reference address for the current process. At the customary offset (minus 2) from this new reference address will be found a pointer to the workspace for the next process to be scheduled. In the event that there is no next process, then line 4 will be true and LPTR register 74 will have its contents adjusted to point to w as the reference address for the last process (line 5), after which the register 73 for holding a pointer to the reference address of the current process will be adjusted to point to w.

Having now described Figure 4 with reference to scheduling, some functions and operations will be further described with reference to Figure 4.

#### load from workspace

The load from workspace function copies the contents at a specific memory location and puts it implicitly into the A register. This function and configuration of the preferred embodiment implicitly refers also to the memory whose address is defined by an offset from the current workspace pointer which serves as a reference. This reference address is always stored in the WPTR register 73, and the offset is contained in the operand register 65. The expression, "memory [WPTR + OREG]" therefore refers to the contents of the memory whose address is found by adding (summing) the contents of WPTR register 73 and register 65. A "load" refers to the A register 71.and the contents of the stack will be shifted down by one register, i.e. the contents of the A register will be shifted into the B register (to make room for the data to be loaded into AREG), and the contents of BREG will be loaded into the C register, if any. With reference to Figure 4, if WPTR is 10000, then "load from workspace" using codes 0 2 will mean load variable 2 into the A register.

This "store to workspace" instruction implicitly means move whatever is in the A register 71 into the memory space whose address is offset from the reference address (contained in MPTR register 73) by the offset contained in the operand register 65. Also, the stack moves up (BREG moves into AREG, and CREG moves into BREG). Referring to Figure 4 if MPTR = 10000 and OREG = 1, then this function means store the contents of the A register 71 into memory into memory location 10001, which is variable 1.

# load pointer into workspace

The function "load pointer into workspace" does not store any data into the workspace. Instead, it loads the A register 71 with a pointer to a particular location in workspace. This will be used, for example, in connection with the "load from vector" instruction which references a particular portion of a vector which can be stored in the workspace. Thus, referring to Figure 4 a workspace 32 will be referred to by the workspace pointer WPTR which is 10000. At a known location within the workspace, there can be a vector. The vector will have a plurality of locations such as 10200, 10201 and 10202. The beginning of the vector will be a particular offset (200) away from the workspace pointer (10000). Thus, to find the beginning of the vector, the offset (200) will be loaded into the operand register 65 and then the instruction "load pointer into workspace" will place the address 10200 into the A register, which points to the beginning of the vector. Thereafter, the "load from vector" operation will be used to find particular memory locations with respect to the beginning of the vector, and therefore it uses the offset in the operand register 65 but in combination with the A register 71 instead of the workspace pointer register 73.

# load literal

The "load literal" instruction literally loads whatever is in the operand register 65 into the A register 71 (the top of the evaluation stack). With respect to Figure 5, the last four bits of any given instruction will be loaded into the operand register 65, but by use of the prefixing functions, more than 4 bits can be stored in the operand register Illustratively, however, an instruction having the codes in decimal notation of 6 13 would mean load the number 13 into the A register 71 and shift the previous contents of the A register into the B register 72.

## jump

The "jump" function is used for branching in a program. The instruction to be executed next by the processor for the current process is pointer to by the contents of the IPTR register 67 which contains the instruction pointer. The jump instruction adds the contents of the operand register 65 to the instruction pointer. Through use of the prefixing functions, the instruction pointer can have values added to it or subtracted from it, to jump forward or backward in a program.

#### call procedure

The "call procedure" function uses the "moveto" procedure which was described above. "Call procedure" first stores IPTR in memory at the customary location for the instruction next to be executed (e.g. memory location 9999 in Figure 4). Next it transfers into the instruction pointer register 67 the contents of the A register 71 which will have been loaded with the pointer to an instruction next to be executed after the "call procedure" function is completed. Then the A register 71 is loaded with the workspace pointer. Following this, the "moveto" procedute changes the reference pointer WPTR so that usually it points to a different address in the current workspace. It will be remembered that "moveto ( )" procedure will set the contents of the WPTR register 73 to whatever is within the parenthesis following the word "moveto". Thus, after a "call procedure," the system now has the workspace pointer pointing to a different location within the same workspace for the current process and is prepared to execute a different instruction which was previously contained in the A register 71. The converse operation is effected by use of the RETURN operation.

## run process

This operation "run process" is generally used in the creation of a process which will have its own workspace and set of instructions. The A register 71 will have been loaded with a workspace pointer for the workspace for the new process, and the B register 72 will have

been loaded with a suitable instruction pointer for the new process. Operation "run process" stores the instruction pointer in memory at the proper offset from the workspace pointer, and then it calls the procedure PROC run (), discussed above, using the workspace pointer in the parentheses. As discussed, this will schedule the new process, i.e. it will add the new process to the linked list.

### pause

The "pause" operation appears in a program to prevent any single process from using the ALU 55 to the exclusion of other processes. This operation is inserted into loops by the compiler. This operation adds the current process to the end of the linked list, stores the necessary pointers, causes the current process to cease execution for the time being, and makes the next process on the linked list the current process. The contents of the evaluation stack are <u>not</u> preserved because "pause" is executed at a time when such contents can be discarded without harming the process.

# join

This "join" operation is used for example when there are concurrent processes, and it is intended that they should all be at a point in the program at the same time. Consider an original process P(0) which at a certain point in the program, P(0) spreads into n concurrent subprocesses P(11), P(2), P(3)...P(n). When these are done, a final process P(n+1) is to execute. However, such final process should not occur until all of P(1)...P(n) have terminated. The "join" operation is used for this. A counter is set up in the workspace, and the A register 71 points to the memory where the count is stored. The count corresponds to the number of subprocesses (which are still active (not terminated). Each subprocess ends with a "join" operation. After a subprocess reaches its "join" operation, it checks the count. If the count is zero, then the program moves to the final process using the "moveto" procedure. If the count is not

zero, the count is decremented by one count, and then the subprocess is caused to "wait" as described above. The other subprocesses are executed until zero count is reached.

#### synchronise

The "synchronise" operation is quite important to concurrent processing, for its use assures that two processes will be at the same point at some time. This will be discussed further in connection with Figure 9 and the discussion entitled, "Communication Between Processes On The Same Microcomputer." Briefly however, if two processes X and Y on the same chip wish to communicate, presumably because one process is computing data which the other process needs. a channel 40, 41, 42 or 43 (Figure 2) is used. Each process will have a "synchronise" operation. The first process to reach its "sync" operation will look at the channel. The channel address will have been loaded into the A register 71, so "memory [AREG]" refers to the channel. The expression "NIL" refers to a predetermined datum recognised as a nil. If NIL is found in a first part of the channel. by the first process, such process will place its workspace pointer into the first part of the channel and then will deschedule itself. It now waits for process Y to reach its "sync" operation. When this happens, process Y will check the first part of the same channel, and it will not find NIL but will instead find some workspace pointer. In response, it schedules process X (adds it to the end of the linked list). The first part of the channel returns to NIL. Generally there will be at least a second part to the channel where data for transfer from one process to the other will be placed. Also, synchronise operations generally occur in pairs. The first "sync" operations in two processes can cause the process to wait for data and then transfer it when it is ready. The second "sync" instructions cause acknowledgments. Thus, a process which is inputting data from a process will "sync". If the data is not ready, it will "wait". When the data is ready by the supply process, that supplying process

will schedule the receiving process, which will then take the data. Then "sync" instructions by each acknowledge the transfer. The first "sync" by the process supplying the data will indicate that the data is ready to be taken.

# COMMUNICATION BETWEEN PROCESSES ON THE SAME MICROCOMPUTER

As already explained, the microcomputer permits communication between processes which may be on the same microcomputer or on different microcomputers. For example, one process may be the measurement of distance travelled by a motor car and a second process the measurement of consumption of fuel relative to distance travelled for that vehicle. The first process may receive as an input, data representating rotations of the vehicle wheel and provide an output representing miles travelled. The second process may receive as an input data relating to fuel quantity consumed but it also needs to communicate with the first process to derive information about distance travelled before it can provide a useful output regarding fuel consumption relative to distance. In the case of process to process communications on the same microcomputer communication is carried out in this example through the channels 40 to 43 indicated on Figure 2. This operation involves the use of the synchronise operation, this requires a program instruction consisting of function code 13 and operation code 11 from the above list of functions and operations. Each channel 40 to 43 consists of two consecutive word locations in memory, one providing a "process location" and the other a "data location". The channel is a unidirectional communication channel which is shared by two and only two processes at any one time. When an active process x wishes to communicate with a process y on the same microcomputer, it follows a sequence which will be described with reference to Figures 9a to 9e. Firstly, process x identifies the address of the channel (marked 40) and loads the data it wishes to communicate into the data location of the channel. It also executes an instruction for a synchronise operation. Provided the process location does not already have the workspace pointer of

the process y awaiting to receive the data, the synchronise operation causes the WPTR of process x to be recorded in the process location and uses a "wait" procedure to deschedule process x. This is the position shown in Figure 9b. Process x now waits until process y is ready to receive the data. When process y wishes to receive the data it carries out an instruction for a synchronise operation to see if the communication channel 40 is ready to transmit data. In carrying out this instruction, process y locates the workspace pointer of process x in the process location of channel 40 and as can be seen from the synchronise operation set out in the list of operations, the execution of a synchronise operation causes a "run" procedure to remove the workspace pointer of process x from channel 40 and add process x to the end of the list of processes waiting to be executed. This is the position in Figure 9c. Process y then reads the data from the data location of channel 40 and then operates a further instruction for a synchronise operation to indicate that it has received the data. This loads the workspace pointer of process y into the process location of channel 40 and causes process y to wait. This deschedules process y leaving the channel 40 in the condition shown in Figure 9d. Once the list on which process x is waiting reaches process x so that process x is reactivated, it performs a further instruction for a synchronise operation which now locates the workspace pointer of process y in the process location of channel 40 and this allows process x to continue to be operated. At the same time it causes a "run" procedure on process y so that process y is again added to the end of the waiting list of processes and is ready to run. The communication channel 40 is then in the condition shown in Figure 9e with process x continuing and process y waiting on the list. In this way, synchronisation of communication is achieved by both processes operating a "handshake" operation in which both processes execute two instructions for synchronise operations one of which deschedules the process and that descheduled process is only put back onto the list when an appropriate signal has been received from the other of the communicating processes.

A specific example of programs and instruction sequences necessary to

carry out two communicating processes on the same microcomputer will now be described with reference to Figure 10. This illustrates the two processes referred to above for measuring miles travelled and fuel consumption of a motor vehicle. The microcomputer 170 has in its memory space a first workspace 171 for the first process which is counting the variable "rotations" and a second workspace 172 for the second process which is counting the variable "miles". Workspace 171 has a word location 173 containing the address of the input channel 174 called "rotation" which forms part of a serial link arranged to receive a message for each wheel revolution from an external revolution detector (not shown). The workspace 171 has a further word location 175 containing the address of a two word memory channel 176 called channel "mile" which in this case receives an output from the process of workspace 171 indicating 1 mile of travel for each 1000 revolutions of the vehicle wheel.

For this first process the program using OCCAM language is as follows:

```
    YAR rotations:
```

- 2. WHILE TRUE
- SEQ
- 4. rotations:= 0
- WHILE rotations < 1000</li>
- 6. SEQ
- 7 rotation ? ANY
- g rotations:= rotations +1
- mile! ANY

Line numbers are not part of the program but have been added to facilitate explanation. Line 1 declares a variable to exist; it is called "rotations". Line 2 is an endless loop because the condition TRUE is always true. Start with zero rotations (line 4). Line 7 waits for any input from the channel names "rotation." When one is received, the variable "rotations" is incremented one. Eventually there will have been 1000 rotations, and Line 5 will be false. Lines 6, 7 and 8 will then be skipped and Line 9 will output a datum to the channel named "mile".

The compiler will convert these OCCAM statements to the following machine instructions:

Instruction	Sequence

Program	in	OCCAM	Language

		Fu	nction		
			code	Data	
					VAR rotations:
					WHILE TRUE
					SEQ
1. L1	:	-			
2.	1d1	0	6	0	rotations := 0
3.	stw	0	1	0	
4. L2	:				WHILE rotations <1000
					SEQ
5.	1 dw	0	0	0	
6.	pfix		14	3	
7.	pfix		14	14	
8.	1d1	1000	6	8	
9.	opr	.gt	13	2	
10.	jnz	L3	9	9	
11.	1 dw	1	0	1	rotation? ANY
12.	opr	sync	13	11	
13.	1 dw	1	0	· 1	
14.	opr	sync	13	11	
15.	1 dw	0	0	0	rotations:=rotations+1
16.	adl	1	7	1	
17.	stw	0	1	0	
18.	opr	pause	13	9	,
19.	nfix		15	0	
20.	j	L2	8	0	
21. L3	:				
22.	1 dw	2	0	2	mile ! ANY
23.	opr	sync	13	11	
24.	1 dw	2	0	2	
25.	opr	sync	13	11	
26.	opr	pause	13	9	
27.	nfix	2	15	2	**
28.	j	L1	8	7	

Once again, line numbers have been added for explanatory purposes only. Lines 1, 4 and 21 are simply reference locations in the program. Line 2 loads the value 0 into A register 71. Line 3 stores the data in the A register into workspace. Because the data part of the instruction is O. there is no offset from the reference address for this process. Thus, the workspace pointer register 73 now contains a workspace pointer MPTR which points to a reference address in memory where 0 is stored for the variable "rotations". Line 5 loads the A register 71 from workspace. Because the data portion of the instruction (which would be loaded into operand register 65) is 0, the offset from the reference address WPTR of the workspace is 0. In lines 6, 7 and 8 the decimal value 1000 is to be added. This requires a prefixing operation because 1000 cannot be represented using four binary bits in the data portion of the instruction. Thus, function code 14 (pfix) is used. The decimal number 1000 in binary is 1111101000. Because this requires ten bits, and the data portion of standard instructions is four bits, three steps are required to load this value into the operand register. Line 8 includes the code for the "load literal" function, so at this time, the A register 71 will be loaded with the binary value of 1000. This causes the transfer of the contents of the A register (which are 0) to the B register 72.

Line 9 calls for an indirect function, the operation "greater than".

This causes a comparison of the A and B registers. Unless the B register contents are greater than the A register contents, this operation will result in FALSE (0).

Line 10 is the "jump nonzero" operation. If the results of line 9's operation were true, then the A register would be set to a nonzero value, and line 10 would cause a jump of 9 lines forward, indicated by the number "9" in the data part of the code. This should jump the program ahead to line 21, the output portion. Assuming that 1000

rotations have not yet been counted, line 11 is next executed. This load from workspace function has an operand of \*1, which means the offset from the reference address is +1. At this memory address will be found the address of the channel named "rotation" and this address will be loaded from the workspace into the A register 71. Line 12 causes a synchronise operation. Line 13 again loads the address of the channel "rotation" and line 14 again synchronises to complete the input operation. In this simple example, no data is transferred. Line 15 now loads the variable which is in workspace, offset O, into the A register, i.e. loads the current value of "rotations" into the A register. Line 16 literally adds the data value 1 to the contents of the A register. Line 17 stores the contents of the A register in the workspace at an offset equal to 0. Hence, the variable "rotations" has now been incremented in response to receipt of data from the channel "rotation". Line 18 is a pause operation which allows the next process to be executed, adding this present process to the end of the list. Note that at this point in the program, the contents of the A register 71 and B register 72 are not relevant to the process. Lines 19 and 20 executes a jump backwards using the negative prefix function. Line 22 loads the contents of the workspace which is offset 2 locations from the reference location. This will be the address of the channel named "mile" and it will be loaded into the A register. A sync operation is performed at line 23. The output is completed by a further "sync" which occurs at line 25. At line 26 another pause is inserted to cause the next process to schedule and to add this process to the end of the linked list. At lines 27 and 28, a jump backwards is executed using negative prefixing. The second process relating to the variable "miles" uses the workspace 172. The workspace 172 has a word location 177 containing the address for the "mile" channel 176 which is used to provide an input to the process of workspace 172. A further word location 178 has the address of a second input which in this case is a channel 179 called channel "fuel" forming part of a serial link

arranged to receive a message from an external fuel gauge (not shown) each time a gallon of fuel is consumed. The workspace 172 has a further word location 180 having the address of an output channel 181 called channel "consumption" forming part of a serial link arranged to output the distance travelled while the last gallon of fuel was consumed. Clearly the process in workspace 172 needs to communicate with the process in workspace 171 in order to obtain via channel 176 messages indicating the number of miles travelled. The instruction sequence and program for the process in workspace 172 are as follows:

Instruction sequence			_		Program in above defined OCCAM
		F	unction <u>code</u>	<u>Data</u>	
					VAR miles:
					SEQ
L1:					
	1d1	0	6	0	miles := 0
	stw	0	1	0	WHILE TRUE
L2:					ALT
	1 dw	1	0	1	mile ? ANY
	1 dv	0	4	0	
	opr	eqz	13	1	•
	jnz	13	9	9	
	1 dw	1	0	1	•
	opr	sync	13	11	
	1 dw	1	0	1	
	opr	sync	13	11	
	l dw	0	0	0	miles := miles + 1
	adl	1	7	1	
	stw	0	1	0	
	pfix	1	14	1	
	j	L4	8	0	

Instruction	sequence	(contd	Program in above defined OCCAM	
		ode	Data	(contd)
L3:				
1 dw	, 2,	0	2	fuel ? ANY
1 dv	0	4	0	
opr	eqz	13	1	
jnz	L4	9	12	
1 dw	2	0	2	
opr	sync	13	11	
1 dw	2	0	2	
opr	sync	13	11	
				SEQ
1 dw	.3	0	3	consumption : miles
1 dw	0	0	0	
stv	1	5	1	
opr	sync	13	11	•
1 dw	3	0	· 3	
opr	sync	13	11	
1d1	0	6	0	miles := 0
stw	0	1	0	•,
L4:				
opr	pause	13	9	
nfix	1	15	1	
. j	L2	8	0	-

# COMMUNICATION BETWEEN PROCESSES ON DIFFERENT MICROCOMPUTERS

A network of interconnected microcomputers is shown in Figure 11 in which four microcomputers are illustrated. It will be understood that the network may be extended in two or three dimensions as required. Each of the microcomputers is of similar structure and is interconnected with the serial link of another microcomputer by two unidirectional wires 185 and 186 each of which extends between the output pin 27 on one microcomputer and the input pin 26 of another microcomputer. The wires 185 and 186 are each used solely for these two pin to pin connections and are not shared by other microcomputers or memory connections. Communication between processes in different microcomputers is effected in generally similar manner using an identical sequence of synchronise operations and this will be described with reference to Figures 2, 11, 12 and 13. In place of the channel 40 (Figure 2), a serial link has an input channel 45 and an output channel 46 each consisting of a process register 47 and data register 48 which can be addressed in the same way as the word locations for the memory channels 40 to 43. They are however operated by control logic 50 which will be described further with reference to Figures 15 and 16.

When data is transmitted through serial links between twomicrocomputers, it is in the form of a series of data strings transmitted serially in the form of packets as shown in Figures 13a and 13b. A data packet is transmitted by an output pin 27 to an input pin 26 and has the form shown in Figure 13a. It starts with two successive bits of value 1 followed by 16 data bits and a final stop bit of value 0. An acknowledge packet, as shown in Figure 13b is sent from the output pin 27 of a microcomputer receiving a data packet to the input pin 26 of the microcomputer which sent the data packet. The acknowledge packet consists of a start bit of value zero followed by a stop bit of value 0. The output control logic of each serial link arranges for each output pin 27 to transmit bits of value O continuously when it is not sending data or acknowledge packets and consequently the input control logic ignores all signals on the input pins 26 until it receives a 1 start bit of a packet.

When the process register of the input or output channel holds the workspace pointer (WPTR) of a process, the control logic 50 is able to generate requests (called input or output requests) to the CPU (12) for the CPU 12 to schedule the process by adding its workspace pointer to the list awaiting execution. The sync logic 10 provides a selector which is used by the CPU 12 to examine each of the request signals from the serial links in turn. Whenever an active process is descheduled by execution of the "wait" procedure the CPU 12 looks to see if there are any requests from a serial link. If there are several external requests, the CPU 12 services all of them in sequence before executing the next process on the list. The CPU 12 services any requests by scheduling the process held in the process register of the channel which generated the request, and resetting the process register 47 to NIL. The process register 47 of the input or output channels in a link 25 contains the special value READY when that channel is ready to perform communication. The sync operation will cause the procedure "run" which detects the special value READY and instead of scheduling a process, activates the control logic 50 in the link. The control logic in a link may perform a synchronise operation on a channel. The synchronise operation tests the process location of the channel. If the value is NIL, it replaces the value with the special value READY and waits until a sync operation caused by a process instruction on the process register resets the value to NIL. Otherwise, it generates a request to the CPU 12 to schedule the process in the process register as described above, and the CPU then resets the value of the process register to NIL. As a result, a process may use the sync operation to synchronise with the control logic 50 in a link 25 in the same way as it is used to synchronise with another process.

The output control logic 50 in a link 25 first synchronises with a process using the process register in the output channel, then transmits data in data packets from the data register in the output channel via the output pin 27 (Figures 2 and 11), then waits for an acknowledge packet signal on the input pin 26, then synchronises with the process again using the process register in the output channel. The output control logic 50 performs this operation repeatedly. The input control logic in a link first waits for data from the input pin 26 to arrive in the data register in the input channel, then synchronises with a process using the process register in the input channel, then synchronises again with the process using the process register in the input channel, then the input channel, then transmits the acknowledge packet signal to the output pin 27. The input control logic performs this operation repeatedly.

In the following, it is assumed that a process x operated by microcomputer 1 in Figure 11 wishes to output data through a serial link to a process y operated by microcomputer 2. To effect this output, the process x stores the data to be output in the data register 187 of the output channel and executes a sync operation on the process register 188 to cause the serial link to start transmission of the data through the pin 27. The process then executes a further sync operation on the same process register 188 to wait until an acknowledge packet is received through the input pin 26 of microcomputer 1. The acknowledge packet signifies that the process y operated by microcomputer 2 has input the data. To input, the process y executes a sync operation on the process register 189 of the input channel of microcomputer 2 to wait for the data packet to arrive from the pin 26 of the microcomputer 2. It then takes the data from the data register 190 and executes a further sync operation to cause the acknowledge signal to be transmitted from the output pin 27 of microcomputer 2.

Figure 12 shows sequentially the contents of the process registers 188 and 189 during a typical sequence of operations occurring when the processes x and y communicate via the serial link. Reference numerals 188 a-e represent successive states of the contents of the process register 188 and reference numerals 189a-e similarly represent successive states of the contents of the process register 189. First, process x addresses the output channel of microcomputer 1 and loads the data to be output to the data register 187 and performs a sync operation on the output process register 188. Assuming that the process register 188 contains the special value READY 188a, indicating that the serial link is ready to output, the sync operation resets the value of the process register 188 to NIL 188b. As a result the control logic causes the data from the data register 187 to be transmitted via the single wire connection 185 to the input data register 190 in the microcomputer 2. Provided that process y is not yet waiting for the input, the control logic in microcomputer 2 changes the value of the process register 189 from NIL 189a to READY 189b, indicating that the data has been received. Process y then executes a sync operation on the process register 189, which has the effect of changing the value of the process register from READY 189b to NIL 189c. Assuming that microcomputer 2 is ready to transmit an acknowledge signal to microcomputer 1. the control logic changes the value of process register 189 back to READY 189d. Process v then takes the data from the data register 190 of the input channel and executes a further sync operation on the process register 189. This resets the process register 189 to NIL 189e. As a result the control logic transmits an acknowledge signal through the single wire connection 186. This acknowledge signal is received by the input pin 26 of the microcomputer 1 operating process x. Assuming that process x executes a second sync operation before the acknowledge signal is received, process x is descheduled by the procedure "wait", and its workspace pointer is stored in the process. register 188(188c). When the acknowledge packet is received the control logic of the serial link generates an request to the CPU of microcomputer 1 to schedule process x. This request is serviced by the CPU of microcomputer 1 as soon as the current process is descheduled and the CPU adds process x to the end of the list and resets the process register to NIL (188d). The control logic now resets the process register to READY (188e), thereby indicating that the link is ready for a further output. The state of the serial

links is now the same as it was before the communication took place, as shown in the sequence of Figure 12, ready for the next communication.Figure 14 illustrates the operation on two separate microcomputers of the processes previously described with reference to Figure 11. In this case however the workspace 171 for counting rotations is on a microcomputer 191 whereas the workspace 172 for counting miles is on a separate microcomputer 192. The two microcomputers 191 and 192 are interconnected through respective serial links 25. Similar reference numerals are used in Figures 14 and 10 for similar parts. The only change is that channel "mile" 176 in Figure 10 is replaced in Figure 14 by a channel "mile" 176a forming an output channel of a serial link in microcomputer 191 and channel "mile" 176b forming an input channel of a serial link in microcomputer 192. The sequence of instructions and program used to operate the two processes in Figure 14 are generally similar to those already described for Figure 10 except that the address of channel "mile" used by each of the processes will now be the address of a channel of a serial link rather than a channel in memory.

## DESCRIPTION OF LINK CONTROL LOGIC

The control logic 50 (Figure 2) for each of the input and output channels of the serial links will now be described in further detail with reference to Figures 15 and 16 in which Figure 15 shows the control logic for the output channel 46 and Figure 16 shows the control logic for the input channel 45.

To output, the control logic 50 (Figure 2) of a link first synchronises with a process using the output process register 47 (Figure 15), then transmits the data from the output data register 48 to the pin 27, then waits for the acknowledge signal from the pin 26, then synchronises with a process again using the output process register 47. The control logic 50 performs this operation repeatedly.

To input, the control logic 50 (Figure 2) of a link first waits for

data to arrive from the input pin 26 and transfers it to the input data register 48, then synchronises with a process using the input process register 47 (Figure 16), then synchronises again with the process using the input process register, then transmits the acknowledge signal to the pin 27. The control logic 50 performs this operation repeatedly.

The values taken by the output and input process registers 47 may be NIL indicating that neither a process nor the control logic is waiting to synchronise, READY indicating that the control logic is waiting to synchronise, or it may be the workspace pointer of a process waiting to synchronise.

In a link, each process register 47 and each data register 48 is connected to the bus 16 through an address decoder 193. The bus 16 incorporates signal lines for the address, data, and control. Control includes a "write" signal, a "read" signal and a "busy" signal. The "busy" signal is used to ensure that both the CPU and the link control logic do not attempt to change the value of the process register simultaneously.

Each process register 47 in a link incorporates logic 194 to detect if the value in the process register is READY, NIL or a workspace pointer.

The output data register 48 (Figure 15) is connected to the output pin 27 through an AND gate 195 and an OR gate 196. The input data register 48 (Figure 16) is connected directly to the input pin 26.

Associated with each process register in a link is a request latch 197 which may be tested by the CPU. Whenever the CPU performs a WAIT procedure, the state of all request latches is tested. If a request latch is set, the process whose workspace pointer is held in the corresponding process register is scheduled by adding its workspace pointer to the end of the list. The request latch is cleared whenever the CPU writes to the process register.

The input and output of data through the link is controlled by four state machines 282, 283, 284 and 285. Each state machine consists of a state register to hold the current state, and a programmable logic array. The programmable logic array responds to the value of the state register and the input signals to the state machine, and produces a predetermined pattern of output signals and a new value for the state register. A counter 286 is used to count bits as they are transmitted through the link, and a further counter 287 is used to count bits as they are received through the link.

The input and output channel control and data state machines have the following inputs and outputs, wherein the name of the input or output indicates the purpose of the signal.

# OUTPUT CONTROL STATE MACHINE 285

(Figure 15) reference numeral	· signal	purpose
inputs:		
200	Mbusy	Memory bus busy
201	Reset	Transputer reset
202	Pregready	Process Register = READY
203	Pregnil	Process Register = NIL
204	Pregwptr	Process Register holds a
		workspace pointer
205	Datagone	Data transmitted from
		output data register
264	Ackready	Acknowledge received
		by input state machine
outputs:		
210	Setrequest	Set cpu request
211	Datago	Initiate data transmission
212	SetPregready	Set Process Register to READY
213	SetPregnil	Set Process Register to NIL
265	Acktaken	Confirm receipt of acknowledge

## OUTPUT DATA STATE MACHINE 284

# (Figure 15)

reference numeral	signal name	purpose
numeran	name	
inputs:		
201	Reset	Transputer reset
211	Datago	Initiate data transmission
220	Countzero	Test if bit count zero
261	Ackgo	Initiate acknowledge transmission
outputs:		
221	Loadcount	Set Bit Counter to number of
		bits to be transmitted
222	Deccount	Decrease bit counter by one
223	Oneout	Set output pin to one
224	Dataout	Set output pin to least significant
	*	bit of shift register
225	Shiftout	Shift data register one place
205	Datagone	Transmission of data complete
260	Ackgone	Transmission of acknowledge complete

# INPUT CONTROL STATE MACHINE 283

# (Figure 16)

reference numeral	signal name	purpose
inputs:		
200	Mbusy	Memory bus busy
201	Reset	Transputer reset
262	Dataready	Data received from pin
242	Pregready	Process Register = READY
243	Pregnil	Process Register = NIL
244	Pregwptr	Process Register holds a workspace pointer
260	Ackgone	Transmission of acknowledge complete
outputs:		
220	Setrequest	Set cpu request

220	Setrequest	Set cpu request
222	SetPregready	Set Process Register to READY
222	SetPregnil	Set Process Register to NIL
261	Ackgo	Initiate acknowledge transmission
263	Datataken	Confirm receipt of data

#### INPUT DATA STATE MACHINE 282

#### (Figure 16)

reference numeral	signal name	purpose
inputs:		
201 230 231	Reset Datain Countzero	Transputer reset Data from pin Test if bit count zero
outputs:	countzer o	rest in bit count zero
240	Loadcount	Set Bit Counter to number of bits to be received
241	Deccount	Decrease bit counter by one
244	Shiftin	Shift data register one place taking least significant bit from pin
245	Setdataready	Reception of data complete
246	Setackready	Reception of acknowledge complete

The sequences of each state machine are set out below with reference to present state, next state, input and output of each machine.

In any state, the outputs listed under the "outputs" column are one, and all other outputs are zero. All inputs are ignored except those mentioned in the "inputs" column. The symbols  $\/\/$  and  $\/\/$  are used to denote the boolean operations and, or and not respectively.

# OUTPUT CONTROL STATE MACHINE 285

State	Inputs	Outputs	Next state
any sync1	Reset Mbusy	SetPregnil	sync1 sync1
sync1 sync1 syncreq1 syncreq1	(AMbusy) /\ Pregnil (AMbusy) /\ Pregwptr APregnil Pregnil	SetPregready Setrequest	syncreq1 syncreq1 syncreq1 send1
send1 send2 send2 send2 waitack1	ADatagone Datagone Datagone ADatagone AAckready Ackready	Datago	send1 send2 send2 waitack1 waitack1 waitack2
waitack2 waitack2 sync2	Ackready Ackready Mbusy	Acktaken	waitack2 sync2 sync2
sync2 sync2 syncreq2 syncreq2	(ΔMbusy) /\ Pregnil (ΔMbusy) /\ Pregwpti ΔPregnil Pregnil	SetPregready r Setrequest	syncreq2 syncreq2 syncreq2 sync1

# OUTPUT DATA STATE MACHINE 284

State	Inputs	<u>Outputs</u>	Next state
any	Reset		idle
idle	(ΔDatago) / \ (ΔAckgo)		idle
idle	Ackgo	Oneout	ackflag
idle	(∆Ackgo) / \ Datago	Oneout	dataflag
ackflag			ackend
dataflag		Oneout	databits
		Loadcount	
databits	ΔCountzero	DecCount	databits
		Shiftout	•
	•	Dataout	
databits	Countzero		dataend
dataend	Datago	Datagone	dataend
dataend	ΔDatago		idle
ackend	Ackgo	Ackgone	ackend
ackend	ΔAckgo		idle

## INPUT CONTROL STATE MACHINE 283

State	Inputs	Outputs	Next state
any	Reset	SetPregnil	receivel
receive1	∆Dataready		receive1
receivel	Dataready ·		sync1
sync1	Mbusy		sync1
sync1	(AMbusy) / \ Pregnil	SetPregready	syncreq1
sync1	(AMbusy) / \ Pregwptr	Setrequest	syncreq1
syncreq1	ΔPregnil		syncreq1
syncreq1	Pregnil		sync2
sync2	Mbusy		sync2
sync2	(AMbusy) / \ Pregnil	SetPregready	syncreq2
sync2	(AMbusy) / \ Pregwptr	Setrequest	syncreq2
syncreq2	ΔPregnil		syncreq2
syncreq2	Pregnil		receive2
receive2	Dataready	Datataken	receive2
receive2	ΔDataready		acksend1
acksend1	ΔAckgone .	Ackgo	acksend1
acksend1	Ackgone		acksend2
acksend2	Ackgone		acksend2
acksend2	ΔAckgone		receive1

#### INPUT DATA STATE MACHINE 282

State	Inputs	Outputs	Next state
any	Reset		idle
idle	∆Datain		idle
idle	Datain		start
start	ΔDatain	SetAckready	idle
start	Datain	LoadCount	databits
databits	ΔCountzero	Shiftin	databits
		DecCount	
databits	Countzero	Shiftin	dataend
dataend	-	SetDataready	idle

As shown in Figure 16, the input control logic includes a flip-flop 280 connected to the output 246 of the input data state machine 282. A further flip-flop 281 is connected to the output 245 of the input data state machine 282. Both control state machines are controlled by clock pulses derived from the clock 28. For some of the links. both data state machines are also controlled by clock pulses derived from the clock 28. For the link shown in Figures 15 and 16, the data state machines are controlled by clock pulses derived from a different clock 22 related in phase to clock 28, which allows this link to operate at a lower speed. Two different clock frequencies can be obtained in order to achieve maximum efficiency depending on the type of microcomputer network which is operated. When microcomputers are grouped closely together communications between them can be carried out more quickly in which case a higher clock frequency can be used. A lower clock frequency can be used to enable satisfactory communication where the microcomputers are more remote and require a lower operating speed.

In both the input and output channels the control state machine monitors the content of the process register 47 and when appropriate generates a CPU request on line 199 by setting the latch 197.

The output control state machine 285 first synchronises with a process using the output process register 47. It then uses the "datago" signal 211 to cause the output data state machine 282 to output the data in the output data register 48 through the pin 27. The output data state machine 284 sends the data in the manner described with reference to Figure 13a and shifts the data in the register 48 until a count in the counter 286 expires. When it has done this it returns the "datagone" signal 205 to the output control state machine to indicate that the transfer of data is complete and that the "datago" signal should be removed. The output control state machine then waits for the "ackready" signal 264 from the latch 280, signifying that the input data state machine 282 has received an acknowledge packet as described in Figure 13b from the pin 26. In

response to the "ackready" signal 264, the output control state machine outputs an "acktaken" signal 265, which resets the latch 280. The output control logic then uses the output process register 47 to synchronise again with the outputting process.

The input data state machine 282 and the microcomputer at the other end of the link is waiting for "start bit" to appear on the input pin 26. When a data packet is detected, the input data state machine 282 of that microcomputer shifts data into the data shift register 48 until the counter 287 indicates that the appropriate number of bits have been received, and then sets the "data received" latch 281. The input control state machine 283 detects the "dataready" signal 262 and responds by resetting the "data received" latch 281. It then synchronises with an inputting process using the input process register 47. It then synchronises again with the inputting process using the process register 47 to confirm that the process has taken the data from the data register 48, and then uses the "ackgo" signal 261 to cause the output data state machine to transmit an acknowledge packet via the pin 27. When the output data state machine 284 is not transmitting data it generates the start and stop bits which constitute the acknowledge packet described in Figure 13b. The input data state machine 282 of the microcomputer which transmitted the data packet detects the acknowledge packet and sets the "acknowledge received" latch 280. As described above, the output control state machine 285 of the transmitting microcomputer has been waiting for this and on detecting the signal resets the latch 280 and performs a second synchronise operation. The state of the link logic in both the output and input links is now the same as it was before the communication took place so that it is ready for the next transmission.

#### CHIP AND MEMORY FORMATION

As mentioned above, the microcomputer of this example is particularly advantageous in having sufficient memory in the form of RAM on

the chip (integrated circuit device) to enable the microcomputer to operate without the necessity for external memory, although external memory can be used when required. There are a number of problems in providing sufficient space for adequate memory on the same chip as the processor. It is necessary to minimise the area required for each memory cell as well as reducing noise interference in the RAM from asynchronously operating circuitry such as a processor on the same chip, while at the same time providing a satisfactory manufacturing yield of acceptable microcomputers from a number of silicon chips, particularly as the memory may be the largest and densest component created on the chip.

In order to minimise the chip area required for each memory cell, this example uses static RAM cells (SRAM) using high impedance resistive loads rather than the more conventional depletion transistor loads or complementary pull-up transistors. The manufacturing technology used in this example employs a film of high resistivity polycrystalline silicon in which the resistive loads are formed. The memory may have 32 K bits of SRAM where each cell consists of transistors having gates formed in a film of polycrystalline silicon. The transistor gates and resistive loads may be formed in the same, or different films of polycrystalline silicon.

Resistor load SRAMs are susceptible to interference from electrical noise injected into the silicon material in which they are formed and stored data can be corrupted by any minority carriers which may be present. In order to shield the SRAM from noise generated by other on chip circuitry and from minority carriers injected by other on chip circuitry the SRAM is formed in an electrically isolated area of silicon as shown in Figure 17. An n-channel substrate 300 is formed with separate p-wells 301, and 302. The array of RAM cells are isolated from other circuitry and associated substrate noise by locating the RAM array in the p-well marked 301. This isolates the RAM cells from minority carriers generated in the substrate by the well-to-substrate potential barrier and any minority carriers generated within the well have a high probability of being collected

in the substrate. In Figure 17, the RAM array will be an n-channel array located in the p-well 301. Any n-channel transistors of peripheral circuitry are isolated from the RAM array by placing them in a further p-well 302.

This technique is fully compatible with either NMOS or P-well CMOS manufacturing technology. In the current example P-well CMOS is used and any p-channel transistors of peripheral circuitry are placed on the n-substrate and isolated from the RAM array by the well-to-substrate potential barrier. Each well containing a memory array is surrounded by a metal ground which contacts the memory array well around its periphery via a heavily doped p diffusion. Within the memory array there is a p diffusion contacting the well to ground for each pair of cells. Substrate bias is unnecessary.

In order to provide acceptable manufacturing yield of products from silicon chips, memory redundancy is incorporated. The memory is divided into rows and columns accessible respectively by row and column decoders. In addition to the normal rows and normal columns the redundancy provides some additional rows and columns together with spare row and column decoders in order to obtain access to the spare rows and columns. The spare column decoders and spare row decoders each incorporate fuses which for example can be open circuited by use of a laser so that when any defective rows or columns are determined during test, fuses can be open circuited by laser techniques to disable the row or column decoder of any normal rows or columns which have been found to be defective and the replacement row or column from the redundant rows and columns can be brought into an enabled position by programming the appropriate spare row decoder or spare column decoder with the address of the defective row or column.

In order to allow N-well CMOS manufacturing technology to be used the following alternative isolation technique may be employed. Referring to Figure 18 a low resistivity P type substrate (405) is used on which a high resistivity P type epitaxial layer is formed.

The cell array is formed in this epitaxial layer in region (401) and is entirely surrounded by a deep N-well diffusion (402). Minority carriers generated by other circuitry in region (403) will be attracted to the N-wells (402) where they become harmless majority carriers, or will recombine in the heavily doped P-type substrate (405). P-channel transistors are placed in N-wells (404) where they are isolated by the well to substrate potential barrier.

#### ADDITIONAL MATERIAL

The invention is not limited to the details of the foregoing example. For instance, although the serial links shown in Figure 2 have separate process registers 47, the function provided by the registers 47 may be effected by memory locations in the RAM 19. In this case the CPU must be able to identify the serial link which it is serving and this may be achieved by connecting each channel of each serial link separately to the sync logic 10 in Figure 2.

One set of data registers and buses is shown in Figure 3 and in some cases it may be desirable to include two such sets in one microcomputer, or even to have two CPUs in one microcomputer.

The principle described above of using pfix and nfix functions to vary the length of operand is applicable to a microcomputer of any word length.

The invention is not limited to a machine operating with 16 bit words nor to 16 bit operand registers, e.g. processors having a word length of 8 bits or multiples of 8 bits may use these instructions. The invention is particularly applicable to 32 bit word microcomputers.

The CPU may include further registers, in an evaluation stack, such as a CREG or even DREG in addition to the A and B registers. Some functions and operations may then be modified to allow the additional registers. For example:

Areg := Breg may be replaced by SEQ

Areg := Breg

Breg := Creg

Creq := Dreq

Breg := Areg may be replaced by SEQ

Dreg := Creg

Creg := Breg

Breg := Areg

Other functions or operations may of course be added to exploit the extra registers. Although the illustrated embodiment described herein and shown in Figure 3 includes only an A register and a B register, in a preferred embodiment of the present invention, three registers are used in a stack.

It will be appreciated that in the above description, the function set lists a plurality of functions followed by an extendable list of operations which may be selected by use of the indirect function "operate". In all cases these functions and operations can be considered as forms of instruction usable in the program to operate the microcomputer. However in order to obtain the advantages discussed above for a fixed format of "instruction" as shown in Figure 5, the list of functions and operations can be considered as a set of primary instructions (consisting of the direct functions, prefixing functions and indirect functions) and a set of secondary instructions (consisting of the operations which may be selected by use of the indirect function). To maximise efficiency, the primary instructions which are most commonly used require only 4 bits of the instruction format shown in Figure 5 and so the other 4 bits can be used for data to be loaded into the operand register 65 and used as an operand for the instructions. For the secondary instructions which are less commonly used, all 8 bits of the instruction format shown in Figure 5 are needed to identify the instruction required.

Consequently the fixed format of the instruction shown in Figure 5 allows no data to accompany a secondary instruction and secondary instructions therefore operate on data held in registers other than the operand register 65.

Although the instruction format shown in Figure 4 comprises 8 bits divided into two halves, it will be understood that other bit lengths may be used and the division into function and data need not necessarily provide equal bit lengths for the two parts.

It is to be appreciated that the present arrangement described herein provides a combination which dramatically improves the efficiency and throughput of the microcomputer. By using instructions having a constant format, by having a function set where the most often used functions are directly available whereas other functions are indirectly available, by arranging for communication between processes and synchronisation among them , by permitting point-to-point communication between microcomputers, and by providing memory on the same chip as each microprocessor, a microcomputer according to various aspects of the invention can achieve a speed of 10 million instructions per second. An array housed on a board of only 10 inches by 20 inches should be able to achieve a speed of 1000 million instructions per second. A Transputer (trade mark) microcomputer array using OCCAM (trade mark) should be able to achieve speeds approximately two orders of magnitude faster, than, for example, a Motorola 68000 using PASCAL. A single Transputer programmed in OCCAM should be about two or three times faster than a single 68000 microprocessor using PASCAL. In the prior art, when microcomputers are added in an array, the incremental gain in performance is progressively less and less with an increase in processors. However, by using the microcomputer of this example, the increase in performance is a linear function of the number of processors. Thus it will be appreciated that the present combination achieves dramatically increased performance over the state of the art.

#### CLAIMS:

- A microcomputer comprising memory and a processor arranged to
  execute a plurality of concurrent processes in accordance with a
  plurality of program steps, said program steps consisting of a
  plurality of instructions for sequential execution by the processor,
  each instruction including a set of function bits which designate a
  required function to be executed by the processor, wherein
  - (a) said processor comprises:

concurrent processes.

- (i) a plurality of registers and data transfer means for use in data transfers to and from said registers.
- (ii) means for receiving each instruction and loading into one of the processor registers a value associated with that instruction, and
- (iii) control means for controlling said data transfer means and registers in response to said function bits to cause the processor to operate in accordance with said function bits,
- (b) the microcomputer includes scheduling means comprising:
  - means for indicating the current process which is being executed by the processor,
    - (ii) means for identifying one or more processes which form a collection awaiting execution by the processor,
    - (iii) means for adding to the said collection one or more further processes,
    - (iv) next processor indicator means to indicate the next process in said collection to be executed by the processor, and
  - (v) a program stage indicator for each concurrent process,
- (c) the processor being arranged to respond to selected instruction to terminate execution of the said current process by the processor and to respond to the said next process indicator means to make the process indicated the current process, whereby the processor is operated to share its processing time between a plurality of

- 2. A microcomputer according to claim 1 in which said memory provides for each process a workspace having a plurality of addressable locations including locations for recording variables associated with the process, and in which one of said processor registers is arranged to hold a workspace pointer value identifying an address of the workspace of the current process.
- 3. A microcomputer according to claim 2 in which said processor is arranged to respond to an instruction to cease executing a current process by replacing the workspace pointer value in said one of the processor registers by the workspace pointer value of a further process in said collection.
- 4. A microcomputer according to claim 2 or claim 3 in which the workspace of each process includes means for indicating the program stage for that process when the process next becomes the said current process.
- 5. A microcomputer according to any one of claims 2 to 4 in which said workspace for each process includes means for holding a workspace pointer value for a subsequent process in the collection, said means being used when one process is in the collection to indicate the process which is to be executed by the processor following said one process, thereby forming a linked list of processes awaiting execution.
- A microcomputer according to claim 5 in which a further processor register is arranged to hold a workspace pointer identifying an address of the workspace of the last process on the list.
- 7. A microcomputer according to claim 6 in which said means for adding an additional process to said collection comprises means for writing a workspace pointer value for the additional process into the workspace of the last process on the list.


- 8. A microcomputer according to claim 7 in which the processor is arranged to respond to an instruction which causes a further process to be added to said list by loading into said further processor register a workspace pointer value for that further process and storing that workspace pointer value in memory of the workspace of the process whose workspace pointer value was last held in said further processor register.
- 9. A microcomputer comprising memory and a processor arranged to execute a plurality of concurrent processes in accordance with a plurality of program steps, said program steps consisting of a plurality of instructions for sequential execution by the processor, each instruction including a set of function bits which designate a required function to be executed by the processor wherein:
  - (a) said processor comprises:
    - (i) a plurality of registers and data transfer means for use in data transfers to and from said registers
    - (ii) means for receiving each instruction and loading into one of the processor registers a value associated with that instruction, and
    - (iii) control means for controlling said data transfer means and registers in response to said function bits to cause the processor to operate in accordance with said function bits.
  - (b) the microcomputer includes scheduling means comprising
    - (i) means for forming a linked list of processes awaiting execution by the processor
    - (ii) means for indicating the current process which is currently executed by the processor, and
    - (iii) means for indicating the last process on the list of processes awaiting execution,
- (c) said memory provides for each process a workspace having a plurality of addressable locations, each said workspace providing:
- $\begin{tabular}{ll} \begin{tabular}{ll} (i) & memory locations for recording variables associated \\ \end{tabular}$  with the process
  - (ii) a program stage indicator for the process


- (iii) next process indicator means for use when the process is on said list for indicating the next process on the list and
- (d) the processor is arranged to respond to selected instuctions to stop execution of the said current process by the processor and to make the next process on the list the current process, and to add a further process to the end of the list when required, whereby the processor is operated to share its processing time between a plurality of concurrent processes.
- 10. A microcomputer according to any one of the preceding claims including one or more communication channels for message transmission between concurrent processes, synchronising means being provided to synchronise message transmission through said channels.
- 11. A microcomputer according to claim 10 in which said scheduling means is responsive to the synchronising means in order to terminate execution of a current process or to add a process to said collection in order to effect synchronisation between concurrent processes.
- 12. A microcomputer according to claim 10 or claim 11 in which said communication channels include memory locations in said memory to permit communication between concurrent processes executed by the same microcomputer.
- 13. A microcomputer according to claim 10 or claim 11 in which said communication channels are provided by one or more communication links which may be connected by dedicated connections to similar links on further devices thereby permitting message transmission with synchronisation between concurrent processes on different microcomputers.
- 14. A microcomputer according to claim 13 in which said communication links each include a register for receiving a pointer value to a workspace or other pointer value indicating the state of the communication channel for use in synchronising message transmission


transmission and scheduling of processes.


- 15. A microcomputer according to any one of claims 10 to 14 in which each communication channel includes store means for storing a pointer value to indicate the state of the communication channel and the processor is arranged to respond to an instruction for synchronisation by testing the state of that channel and if not already occupied by a workspace pointer value for a process, the process which executed the synchronising instruction is terminated and its workspace pointer loaded into said store means for the channel.
- 16. A microcomputer according to claim 15 wherein said processor is arranged so that if the store means of a channel is already occupied by the workspace pointer value of a process when a synchronise instruction is executed, the process whose workspace pointer value is in said store means is added to said collection awaiting execution and a further value which is not a process workspace pointer value is loaded into said store means.
- 17. A microcomputer according to claim 16 wherein the processor is arranged to respond to a synchronising instruction by termination of the current process and thereby removing its workspace pointer value from the process register containing said value, and causing the processor to execute the next process in said collection.
- 18. A microcomputer according to claim 17 wherein said process which is terminated by execution of the synchronisation instruction is returned to said collection awaiting execution when a further synchronise instruction is effected by a further process wishing to communicate with said process.
- 19. A microcomputer according to any one of the preceding claims in which the processor is arranged to respond to an instruction arranged to bring a number of concurrent processes together at a required stage in a program sequence.


- 20. A microcomputer according to claim 19 in which said processor includes counter means arranged to respond to the termination of a process as a result of a selected instruction, said counter means being arranged to indicate when a predetermined number of processes have terminated thereby permitting advance to a further program stage.
- 21. A network of interconnected microcomputers each being according to any one of the preceding claims.
- 22. A network of interconnected microcomputers as claimed in claim 21 each microcomputer having communication links connected to a further microcomputer in the network by a connection dedicated solely to message transmission between the two interconnected microcomputers, the processor of each microcomputer being arranged to effect message synchronisation between microcomputers and to terminate execution of current processes and add further processes to said collection in accordance with the synchronisation effected.
- 23. A method of operating a microcomputer wherein processes awaiting execution by the processor are identified and added to a collection or removed therefrom by execution by the processor and termination of said execution, whereby the processor shares its time between a plurality of concurrent processes.
- 24. A method of operating a network of interconnected microcomputers wherein each microcomputer is arranged to effect message synchronisation between processes on interconnected microcomputers and to schedule and deschedule processes on each microcomputer in accordance with said synchronisation.

























3

Fig.13b. 13b. 1000 PACKET



9|15











Fig .12.







ŧ

